




PME SWT 0100

Weighing module
For Schneider Electric MX80



1. Safety information.....	5
1.1.1. Notice	5
1.1.2. Please Note	5
1.1.3. Before you begin	5
1.1.4. Start up and test.....	6
1.1.5. Operation and adjustment	6
2. About the book.....	8
2.1.1. Document Scope.....	8
2.1.2. Validity note	8
2.1.3. Product Related Information.....	8
2.1.4. Disclaimer.....	8
3. Introduction	9
3.1. General information.....	10
3.2. Product presentation.....	11
3.2.1. Architecture.....	11
3.2.2. Signal processing.....	12
3.3. Operational and Environmental Recommendations.....	13
3.3.1. General.....	13
3.3.2. Dividing up the loads	13
3.3.3. Inhibiting interference on the load receiver	13
3.3.4. Mechanical installation of the weighing sensors	13
3.3.5. Protecting the sensors from interference currents.....	13
3.3.6. Contact with water and corrosive products	13
3.3.7. Preventive maintenance of the installation and accessories.....	13
4. PME DTM Library Installation/Uninstallation Guide	14
4.1. System Platforms.....	15
4.1.1. Minimum Resource Requirements	15
4.1.2. Software Requirements	15
4.2. Detailed Installation Guidelines.....	16
4.3. Detailed Uninstallation Steps.....	21
5. Adding a Third-Party Module to a Unity Pro Project	24
5.1. Create a New Unity Pro Project	25
5.2. Configure the CPU.....	27
5.3. Add a Third-Party Module DTM to the DTM Browser.....	30
5.4. Input the Source IP Address for the CPU	33
5.5. Configure IP Address and DHCP for the Third-Party Module.....	35
5.6. Configure the Third-Party Module's DTM Parameters	37
5.7. Build a Unity Pro Project File and Transfer it to the PLC	38
5.8. Transfer a Third-Party Module Configuration File to the PLC	41
5.9. Run the New Project.....	42
5.10. Resetting Device with Unity	44
6. Remote rack configuration of PME SWT module.....	45
6.1. Remote rack physical configuration with PME modules.....	46
6.2. Device configuration on remote rack in Unity Pro:.....	47
6.3. Device configuration transfer from Unity Pro:.....	54
7. Configuration with Unity Pro.....	56
7.1. Identity tab.....	57
7.2. Application configuration and process data tab	58
8. Module specifications	66
9. Installing PME SWT weighing module	68
9.1.1. Maximum Configuration in PME SWT weighing module	68

9.1.2. Installation precaution	68
9.1.3. Order of Module Installation	68
9.1.4. Mounting a Module	68
9.1.5. Replacing a Module	69
9.1.6. Installation Results	69
9.1.7. External Features	69
9.1.8. PME SWT Keying Pin	70
10. Interfaces	72
10.1.1. Connection	72
10.2. Load cells input	74
10.2.1. 4 and 6-wire load cells	74
10.2.2. Multiple load cells connection	74
10.2.3. Cable extension	75
10.3. Auxiliary RS485 communication port	76
10.3.1. eNodTouch display panel	76
10.4. Discrete Input/output	77
10.4.1. Discrete inputs	77
10.4.2. Discrete outputs	77
10.5. LED Indicators	78
11. Identification parameters	80
12. Scaling parameters	81
12.1.1. Maximum capacity	81
12.1.1. Decimal point position	81
13. Metrological parameters	82
13.1.1. Zero Tracking and Initial Zero	82
13.1.2. Stability criterion	82
14. Flow control parameters	83
15. Process Data parameters	84
15.1.1. Measurement variables	84
15.1.1. Measurement status	84
15.1.2. I/O status	84
16. Functional commands	85
16.1. Sending Functional Commands through Unity	86
16.2. Device Response Register Status	88
16.3. Example with Pre-set Tare Parameter	91
16.4. System commands	92
16.4.1. Reset	92
16.4.2. EEPROM backup	92
16.4.3. Restore default settings	92
16.5. Weighing control commands	93
16.5.1. Zero	93
16.5.2. Tare	93
16.5.3. Cancel tare	93
16.5.4. Cancel last command	93
16.5.5. Logical outputs 1-4 activation/deactivation	93
17. Filters	94
17.1.1. Introduction	94
17.1.2. Bessel low-pass filter parameters	94
17.1.1. Mean-value filter	94
17.1.2. A/D converter parameters	94
18. Discrete Input parameters	96

19. Discrete Output parameters	97
19.1.1. S0 and S1 output parameters	97
19.1.2. S2 and S3 output parameters	98
20. Legal for trade	99
20.1.1. Legal for trade parameters	99
20.1.2. Legal for trade Information (Read only)	99
20.1.3. "Legal for trade" considerations	99
21. Calibration	100
21.1. Introduction	101
21.2. Calibration parameters	102
21.2.1. Calibration loads 1/2/3	102
21.2.2. Sensor sensitivity	102
21.2.1. Zero sensitivity	102
21.2.2. Calibration Zero	102
21.2.1. Global span adjusting coefficient.....	103
21.2.1. Calibration place g value / place of use g value.....	103
21.2.2. Span coefficients 1/2/3	103
21.3. Physical calibration.....	104
21.3.1. Physical calibration commands	104
21.3.2. Physical calibration example.....	105
21.1. Partial Physical calibration	108
21.1.1. Zero adjustment commands	108
21.1.2. Zero adjustment example.....	108
21.1.3. Span adjustment commands	108
21.1.4. Span adjustment example	108
21.2. Theoretical calibration.....	109
21.2.1. Theoretical calibration commands	109
21.2.2. Theoretical calibration example.....	109

1. [Safety information](#)

1.1.1. [Notice](#)

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a Danger safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, **will result in** death or serious injury.

WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, **can result in** death or serious injury.

CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, **can result in** minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

1.1.2. [Please Note](#)

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by SCAIME for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

1.1.3. [Before you begin](#)

Do not use this product on machinery lacking effective point-of-operation guarding. Lack of effective point-of-operation guarding on a machine can result in serious injury to the operator of that machine.



WARNING

UNGUARDED MACHINERY CAN CAUSE SERIOUS INJURY

- *Do not use this software and related automation equipment on equipment which does not have point-of-operation protection.*
- *Do not reach into machinery during operation*

Failure to follow these instructions can result in death, serious injury, or equipment damage.

This automation equipment and related software is used to control a variety of industrial processes. The type or model of automation equipment suitable for each application will vary depending on factors such as the control function required, degree of protection required, production methods, unusual conditions, government regulations, etc. In some applications, more than one processor may be required, as when backup redundancy is needed.

Only the user can be aware of all the conditions and factors present during setup, operation, and maintenance of the machine; therefore, only the user can determine the automation equipment and the related safeties and interlocks which can be properly used. When selecting automation and control equipment and related software for a particular application, the user should refer to the applicable local and national standards and regulations. The National Safety Council's Accident

Prevention Manual (nationally recognized in the United States of America) also provides much useful information.

In some applications, such as packaging machinery, additional operator protection such as point-of-operation guarding must be provided. This is necessary if the operator's hands and other parts of the body are free to enter the pinch points or other hazardous areas and serious injury can occur.

Software products alone cannot protect an operator from injury. For this reason the software cannot be substituted for or take the place of point-of-operation protection.

Ensure that appropriate safeties and mechanical/electrical interlocks related to point-of-operation protection have been installed and are operational before placing the equipment into service. All interlocks and safeties related to point-of-operation protection must be coordinated with the related automation equipment and software programming.

NOTE: Coordination of safeties and mechanical/electrical interlocks for point-of-operation protection is outside the scope of the Function Block Library, System User Guide, or other implementation referenced in this documentation.

1.1.4. Start up and test

Before using electrical control and automation equipment for regular operation after installation, the system should be given a start-up test by qualified personnel to verify correct operation of the equipment. It is important that arrangements for such a check be made and that enough time is allowed to perform complete and satisfactory testing.



CAUTION

EQUIPMENT OPERATION HAZARD

- *Verify that all installation and set-up procedures have been completed*
- *Before operational tests are performed, remove all blocks or other temporary holdings means used for shipment from all component devices.*
- *Remove tools, meters and debris from equipment.*

Failure to follow these instructions can result in injury or equipment damage.

Follow all start-up tests recommended in the equipment documentation. Store all equipment documentation for future references.

Software testing must be done in both simulated and real environments.

Verify that the completed system is free from all short circuits and grounds that are not installed according to local regulations (according to the National Electrical Code in the U.S.A, for instance). If high-potential voltage testing is necessary, follow recommendations in equipment documentation to prevent accidental equipment damage.

Before energizing equipment:

- · Remove tools, meters, and debris from equipment.
- · Close the equipment enclosure door.
- · Remove all temporary grounds from incoming power lines.
- · Perform all start-up tests recommended by the manufacturer.

1.1.5. Operation and adjustment

The following precautions are from the NEMA Standards Publication ICS 7.1-1995 (English version prevails):

Regardless of the care exercised in the design and manufacture of equipment or in the selection and ratings of components; there are hazards that can be encountered if such equipment is improperly operated.

It is sometimes possible to misadjust the equipment and thus produce unsatisfactory or unsafe operation. Always use the manufacturer's instructions as a guide for functional adjustments. Personnel who have access to these adjustments should be familiar with the equipment manufacturer's instructions and the machinery used with the electrical equipment.

Only those operational adjustments actually required by the operator should be accessible to the operator. Access to other controls should be restricted to prevent unauthorized changes in operating characteristics.

[2. About the book](#)

[2.1.1. Document Scope](#)

This document describes the PME SWT weighing module that can be used in X80 RIO drops.

NOTE: The specific configuration settings contained in this guide are for instructional purposes only. The settings required for your specific application can be different from the examples presented in this guide.

NOTE: The architectures described in this document have been tested and validated in various scenarios. If you intend to use architectures different than the ones described in this document, test and validate them thoroughly before implementing.

[2.1.2. Validity note](#)

This document is valid for X80 remote I/O systems when used with Unity Pro 8.0 or later. The technical characteristics of the devices described in this document also appear online.

The characteristics that are presented in this manual should be the same as those characteristics that appear online. In line with our policy of constant improvement, we may revise content over time to improve clarity and accuracy. If you see a difference between the manual and online information, use the online information as your reference.

[2.1.3. Product Related Information](#)



WARNING

UNINTENDED EQUIPMENT OPERATION

The application of this product requires expertise in the design and programming of control systems. Only persons with such expertise should be allowed to program, install, alter, and apply this product.

Follow all local and national safety codes and standards. Failure to follow these instructions can result in death, serious injury, or equipment damage.

[2.1.4. Disclaimer](#)

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Scaime nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information that is contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Scaime.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Scaime software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

3.1. General information

PME SWT is a versatile and flexible weighing module controller, which can be used wherever weighing scales are to be used in the Schneider Electric Mx80 automation system.


The function module PME SWT takes full advantage of all the features of the modern automation system:

- Install on either M580 local CPU rack or X80 RIO rack of Ethernet backplane
- Uniform design technology and consistent communication via Ethernet backbone
- Uniform configuration with UNITY V8.0 or latter.
- Configuration, calibration and diagnose via FDT/DTM.
- Measurement of weight or force with high resolution of 24 bits A/D converter
- High weighing accuracy 0.01 %
- External Measurement response time of 10ms
- Internal measurement rate up to 400 Hz
- 2 Digital outputs for monitoring of limit values
- 2 Digital outputs for 2-feeds dosing control
- Parameter definable inputs and outputs
- Continuous flow rate calculation
- Theoretical adjustment possible without adjustment weights
- RS485 communication port for dedicated local HMI
- Factory Pre-calibration
- Replacement of the module possible without a new adjustment of the scale
- Use in Hazardous area zone 2 and 22 (ATEX approval), class I division 2 (cULus approval)
- Intrinsically safe load cell powering for the hazardous area Zone 1 (With optional SCAIME Zener barrier kits)

3.2. Product presentation


PME SWT is a weighing module controller of the M580 and X80 system. Operation of the PME SWT in M580 and X80 system architecture guarantees complete integration of weighing technology in the automation system.

- Install on either M580 local CPU rack or X80 RIO rack of Ethernet backbone.
- Weighing data can be transferred from weighing module to M580 CPU, Unity and the network via Ethernet backbone
- Unity to configure, monitor and diagnose the weighing module via FDT/DTM



3.2.1. Architecture

The following operation diagram shows the architecture and processes executed by the PME SWT module:




3.2.2. Signal processing

The goal of signal processing is to provide a filtered and scaled measurement to the user. The signal processing is the software part in charge of the metrological functions:

- Digital filtering
- Measurement scaling
- Zero, Tare functions
- Measurement stability control
- Flow rate calculation
- Calibration

The following diagram shows the signal processing operations:



3.3. Operational and Environmental Recommendations

3.3.1. General

The quality of the measurement provided by the module may be reduced considerably if the sensor set-up and installation precautions have not been observed. Thus in place of exhaustive information, these few lines should make you aware of some of the precautions which need to be taken.

3.3.2. Dividing up the loads

In a measurement system, the weighing sensors support the following weights:

- the maximum weight to be weighed,
- The weight of the loading receiver and its structures (or metrological tare).

This total weight is divided up between 1, 2, 3, 4, 6, even 8 sensors. The design of the mechanical structures, the shape of the loading receiver and the dividing of the load on or within the receiver, means that the total weight is not always equally divided between all the sensors (except of course in the case of a single sensor).

It is therefore a good idea to make sure that the dimensions of the weighing sensors are calculated in such a way as to be able to support the total weight (maximum weight + tare) to which they will be subjected

3.3.3. Inhibiting interference on the load receiver

As a weighing sensor deflection is very weak (a few tenths of a millimeter), all interference on the load receiver or any friction on the permanent framework will cause an invalid weight measurement and make correct adjustment of the module impossible.

3.3.4. Mechanical installation of the weighing sensors

The sensors in traction or compression must be used vertically respecting their action direction (traction or compression). The maximum admissible tolerance on the installation's verticality is in the region of the degree according to the installation and the required precision.

3.3.5. Protecting the sensors from interference currents

It is recommended that each sensor be provided with a mass flex which plays the role of the electric "shunt" with the aim of protecting sensors from currents capable of circulating in the metallic framework (ground currents, from the terminal to be connected, and electrostatic discharges...). This flex will be of a sufficient length to not result in mechanical constraints and it will be placed directly next to the sensors, between the permanent framework and the load receiver.

3.3.6. Contact with water and corrosive products

Weighing sensors are manufactured as waterproof. It is recommended, however, that they be prevented from coming into contact with water, corrosive products and direct sunlight.

3.3.7. Preventive maintenance of the installation and accessories

The weighing module requires no special maintenance. The weighing sensors, however, should be cleaned periodically if used in a difficult environment.

It is advisable to periodically test and service the mechanical state of the load receiver.

- Cleaning the receiver and its structures because of a product deposit or various material
- Deposits may result in a noticeable variation of the tare.
- Checking the verticality of the weighing sensors.
- Checking the sensor and actuator states according to their period of use.
- Etc...



WARNING

Statistics show that 90% of breakdowns occurring on a weighing/dosing installation are not attributable to the electric command device, but to the installation itself (defective limit switches, mechanical faults...).

4. PME DTM Library Installation/Uninstallation Guide

This document explains the installation/uninstallation PME DTM Library in general:-

4.1. [System Platforms](#)

PME DTM Library can be installed on different Windows platforms using the same setup package. The setup will detect the platform and the specific installation requirements automatically. The following Windows platforms are supported:

- Windows XP Professional (SP3 or higher)
- Windows 7 32/64-bit (Professional or Ultimate Edition)
- Windows Vista 32/64-bit (Professional or Ultimate Edition)

4.1.1. [Minimum Resource Requirements](#)

Please verify that the target system meets the following minimum requirements:

- Processor type: Intel Pentium single core or compatible platforms with 1GHz
- Processor speed: 1.2GHz (recommended 3.0 GHz)
- Memory: 1024 MB (2048 MB recommended)
- Display: 800x600, 256 colors (1024x768 recommended)
- Free hard disk space on system drive: 8 GB(recommended 20 GB)
- Web Access : Microsoft Internet Explorer 5.5 or higher


4.1.2. [Software Requirements](#)

The Generic Modbus DDXML DTM requires the following software installed on the PC:-


- Microsoft .NET Framework V3.5 SP1
- UnityPro V8.0 / FDT Frame Application compliant to the FDT standard.
- M580 Master DTM/Any EIP Master DTM

4.2. Detailed Installation Guidelines


- Double click on the installer (.exe file) of the PME DTM Library named “Schneider Electric PME DTM Library” to configure the windows installer as shown in the image below.




- Then the library will look for the pre-requisites (Software Requirements) in the target system, if not available then the installation setup will prompt for their installation as shown in image below.




- Click on install to proceed and then the installation of the missing components will get initiated as shown in image below.




- After all the prerequisites (except .NET Framework) get installed the setup will look for .Net framework installation. If missing an error notification will be pop up as shown in the image below.




- Clicking on OK aborts the installation as shown in the image below.



- User will need to install the framework (as .Net Framework is not shipped with the Library Setup) and then restart the library installation.
- After all prerequisites are successfully installed/found in the target machine the installation will start as shown in the image below.




- Accept the End User License Agreement to proceed as shown in the image below.




- Enter the Customer Information.

- Configure the Destination Folder (by clicking on Change. Click on Next to proceed) as shown in the image below.


- Click on Install to proceed as shown in the image below.



- The installation of the library will then start as shown in the image below.




- If all goes right installation will get successfully completed as shown in the image below.



4.3. Detailed Uninstallation Steps


- Go to the control panel and then go to “Add or Remove Programs” in case of windows XP, OR, go to “Programs and Features” in case of Windows 7, then select the entry “Schneider Electric PME DTM Library” from amongst the programs and thereafter click on “Change” to initiate the Uninstallation.
- Click on Next to start the uninstallation as shown in the image below.




After that select the appropriate option from amongst

- Modify : To change which program features are installed. This option displays the Custom Selection Dialog in which you can change the way features are installed.
- Repair : To Repair installation errors in the program. This option fixes missing or corrupt files, shortcuts and registry entries.
- Remove : To Remove Schneider Electric PME DTM Library from your computer.


If you want to uninstall the PME DTM Library then select Remove option and click on Next as shown in the image below.



- The setup will then confirm the option you just selected and will also give you an option to navigate back. To continue the uninstallation click on Remove as shown in the image below.




- The uninstallation setup will reconfirm the uninstallation as shown in the image below , as the library is a shared component




- Click on Yes to proceed with the uninstallation.

The uninstallation wizard moves on to remove the files of the PME DTM Library as shown in the image below.



- After successful removal of the Library click on Finish to exit the setup as shown in the image below.



5. Adding a Third-Party Module to a Unity Pro Project

This document shows you how to add a third-party module to a new project created in Unity Pro version 8.0. In this example, the PME SWT 0100 weighing module is added. Before you begin, confirm that Unity Pro version 8.0 is installed on your PC. When Unity Pro version 8.0 or higher is installed on your PC, a DTM library – which includes the DTM for the PME SWT 0100 module – is also installed on your PC.

Note: You will need to install on your PC the Generic PME DTM. You can download this DTM from the Scaime or Schneider Electric website. Refer to the ReadMe file for the Generic PME DTM for instructions on how to install this DTM on your PC.

This document illustrates how to use Unity Pro to:

Create a new Unity Pro project, selecting both a CPU and a rack, and adding a third-party module, in this example the PME SWT 0100 weighing module.

Configure the CPU, including:

- Setting the main CPU IP address and the IP address used by the CPU for IO scanning
- Enable FTP/TFTP transmissions of configuration files between the CPU and your PC
- Optionally enabling port mirroring, to permit the use of a packet sniffer that can analyze Ethernet packets passing over the CPU's Ethernet ports

Add an PME SWT 0100 module DTM to the project design in the Unity Pro DTM Browser.

Configure the IP address for the connection between the CPU and your configuration PC.

Configure address server settings for PME SWT 0100 module.

Configure DTM parameters for the PME SWT 0100 module.

Build the Unity Pro project configuration file, which does not include the third-party module configuration settings, and then transfer the file to the PLC.


Generate a third-party (PME SWT 0100) module configuration file and then transfer that file to the PLC.

Run the newly created Unity Pro project, and access the calibration page on the PME SWT 0100 module.


5.1. Create a New Unity Pro Project

Create a new Unity Pro project by selecting both a CPU and a rack, then adding an PME SWT 0100 weighing module.


- Open Unity Pro and Select **File -> New Project**.



- In New Project dialog, select an M580 PLC and a rack for the backplane, then click **OK**.
- In the Unity Pro Project Browser, under the Configuration node, double-click on the PLC Bus icon to open the PLC Bus window.
- Place your mouse pointer on an empty slot in the PLC rack, and click the right mouse button to display the following menu:




- Select **New Device...** to open the New Device dialog>



- Select the PME SWT 0100 module and click **OK**.

The PME SWT 0100 weighing module is added to the rack in the specified slot:




5.2. Configure the CPU


The next task is to configure the CPU by:

- Setting the main CPU IP address and the IP address used by the CPU for I/O scanning
- Enabling FTP/TFTP transmissions of configuration files between the CPU and your PC
- Optionally enabling port mirroring, to permit the use of a packet sniffer that can analyze Ethernet packets passing over the CPU's Ethernet ports

In the PLC Bus window, place your pointer on the Ethernet ports of the CPU, then click the right mouse button to display a context menu:



- Select **Open Submodule** to open a configuration window for RIO DIO Ethernet communications.
- Select the IPConfig tab:




- In the IPConfig page, configure the following parameters:

Parameter	Setting
Main IP address:	Type in the PLC address (in this example: 192.168.2.10)
IP address A:	Type in the IP address used by the PLC for I/O scanning (in this example: 192.168.2.11).

Note: Also enter an appropriate Subnet mask and Gateway address.


- In the Edit menu (or on the toolbar) click **Validate**, and then save your edits.
- Select the Security tab:



- In the Security page, click the **Unlock Security** button to enable FTP, TFTP and HTTP communication with the PLC (as depicted above).

Note: Enabling FTP and TFTP communications permits the upload and download of parameter configuration files between your PC and the PLC.

- In the Edit menu (or on the toolbar) click **Validate**, and then save your edits.
- Select the ServicePort tab:



Optionally, you can use the ServicePort page to enable port mirroring and use a packet sniffer to analyze Ethernet packets passing over the CPU's Ethernet ports. To configure port mirroring, enter values for the following parameters:

Parameter	Setting
Service Port:	Select Enabled .
Service Port Mode:	Select Mirroring .
Port Mirroring Configuration:	<p>Select Yes for each port you wish to mirror. In this example, the following ports are mirrored:</p> <ul style="list-style-type: none"> • ETH2 and ETH3: external Ethernet ports on the CPU • Backplane port: the Ethernet port connecting the CPU to the Ethernet backplane

Note: When you configure the service port for port mirroring, you cannot also connect your PC to the service port for the purpose of configuring the CPU.


- In the Edit menu (or on the toolbar) click **Validate**, and then save your edits

5.3. Add a Third-Party Module DTM to the DTM Browser


The next task is to add the DTM for the third-party module (here for the PME SWT 0100 module) to the Unity Pro DTM Browser.

Note: In Unity Pro version 8.0, you need to add a third-party module separately to both the PLC Bus and to the DTM Browser. In future versions of the software, adding the module to the PLC Bus will also add its DTM to the DTM Browser.

- Open the DTM Browser by selecting **Tools -> DTM Browser**.
- In the DTM Browser, select the CPU and click the right mouse button to open a context menu:




- Click **Add** to open the Add dialog:




Note: If the desired third-party module does not appear in the list, close the dialog, and click **Update** in the DTM Catalog tab of the Unity Pro Hardware Catalog. Then return to the Add dialog.

- In the Add dialog, scroll to and select the DTM for the PME SWT 0100 module, and then click **Add DTM**. A device properties dialog opens, where you can edit the alias name of the module:



- Click **OK**.


The selected device DTM is added to the DTM Browser:




5.4. Input the Source IP Address for the CPU

The next task is to input into the CPU configuration a Source IP Address for the Unity Pro project. The Source IP Address is an IP address for a network interface card installed on your configuration PC. Unity Pro uses this address to connect to the CPU and transmit or receive project configuration settings.

- In the DTM Browser, select the CPU and click the right mouse button to open the following context menu:



- Click **Open**. The master DTM properties window opens.
- In the master DTM navigation tree, select Channel Properties to display the following page:



- Input the Source IP Address. In this example, Unity Pro communicates with the CPU at the address 192.168.2.25.


Note: You can also use the settings on this page to configure auto-detection of devices on both the EtherNet/IP and Modbus networks.

- Click **Apply** to save your edits, and leave the window open for additional edits.

5.5. Configure IP Address and DHCP for the Third-Party Module

The next task is to configure the IP address for the third-party module, and identify the module as a DHCP client of the DHCP server that resides in the CPU. This process will add the third-party module to a list of modules, which will be served IP address settings and configuration parameter settings by the DHCP server located on the M580 PLC.

- In the master DTM navigation tree, select the third-party module (in this case the PME SWT 0100 module):




- Click on the Address Setting tab to open that page, then configure the following properties:

Parameter	Setting
IP Address:	Type in the IP address to be assigned to the third-party module (in this example: 192.168.2.15).
DHCP for this device:	Select Enabled to identify the third-party module as a DHCP client.
Identified by:	Select Device Name. Note: Only the Device Name selection is supported for third-party modules. Do not select the MAC Address option.
Identifier:	Type in a concatenated string consisting of the following components separated by the underscore character (_): <ul style="list-style-type: none"> rack name (4 characters) slot number (2 characters) module name (8 characters) In this example, the Identifier setting is: Mx80_05_PMESWT01

Note: Also complete the Subnet Mask and Gateway settings, as necessary.


- Click **Apply** to save your edits, and leave the window open.

To verify that the module is added to the list of devices to be served by the DHCP server, in the master DTM, navigate to and select the Address Server page. There you can see that the third-party module appears in the list of modules to receive IP address and DTM parameter settings from the DHCP server:



The next step is to set the connection time-out multiplier value for the I/O connection from CPU to the third-party module.

- In the master DTM navigation tree, click on the following node:
Device List -> <third-party module> -> Read Input-Write Output data.
- Click on the Connection Settings tab:




- Set the Time-out Multiplier setting to **x128**, then click **Apply**.


5.6. Configure the Third-Party Module's DTM Parameters

After the third-party module DTM is added to the DTM Browser, you can configure parameters that are unique to that module, in this case the Scaime PME SWT 0100 weighing module. Although the module DTM presents many configurable parameters, this example focuses only on those parameters that are minimally necessary for module operation.

- In the DTM Browser, select the third-party module and click the right mouse button to display the following context menu:



- Select **Open**. The third-party module's DTM configuration window opens:




- Optionally, you can click on other tabs to access and configure parameters in those pages.
- When you finish editing parameter settings, click **Apply** to save your edits.

5.7. Build a Unity Pro Project File and Transfer it to the PLC

In this task you will build a file that contains the Unity Pro project configuration settings and transfer that file to the PLC.

Note: The project file you create in this task does not include the DTM configuration settings for the Scaime PME SWT 0100 third-party module. Those settings will be separately generated and transferred to the PLC.


- To build the project, select **Build -> Build All Project**.



Upon completion of the process, the task bar will display the word “Built”.

The next task is to set the address of the PLC for transfer of the newly built project.

- Select PLC -> Set address...




The Set Address dialog opens (see below).


In the Set Address dialog:

- Select the the PLC's IP address from the drop down list (in this example, the address is 192.168.2.10)
- select **TCPIP** as the Media
- click **Test Connection**


Unity Pro indicates if the test is successful:




- Click **OK** to close the message box.
- The next task is to connect Unity Pro to the PLC. Select **PLC -> Connect:**



- Select **PLC -> Transfer Project to PLC:**



The Transfer Project to PLC dialog opens:



- Click **Transfer**. This task completes the transfer of the project file to the PLC, but without the DTM settings for the third-party module.


5.8. Transfer a Third-Party Module Configuration File to the PLC

The next task is to transfer the configuration file to the PLC.

- If the project is running, stop the project by selecting **PLC -> Stop**. If you are asked to confirm stopping the project, click **OK**.

Unity Pro generates a configuration file for the third-party device configuration.

- In the DTM Browser, select the third-party module DTM, click the right mouse button, and then navigate to and select: **Device menu -> Additional functions -> Transfer to FDR Server**:



Unity Pro indicates the transfer was successful




5.9. Run the New Project

The last task is to operate the newly created project. To complete this task, you will need to connect Unity Pro to the CPU DTM and to the third-party module DTM.

Note: The order in which you connect Unity Pro to each DTM is important. First connect Unity Pro to the CPU DTM. Only after this connection is made should you make the connection between Unity Pro and the third-party module DTM.

For the PME SWT 0100 weighing module, you will also want to perform calibration on the module before running the application for the first time. Calibration can be performed only in online mode, after the module has successfully acquired IP address and parameter configuration settings from the FDR server, and is operating normally.

- To start the project, select **PLC -> Run**. If you are prompted to confirm the run command for this project, select **OK**.
- With the project now running, in the DTM Browser select the CPU DTM and then click the right mouse button. The following context menu displays:




- Select **Connect**, to connect Unity Pro to the CPU DTM.

Note: When connected, the IP address and device name appear in **bold** letters.


The next task is to connect Unity Pro to the DTM for the third-party module (in this example, the Scaime PME SWT 0100 weighing module).

- In the DTM Browser select the third-party module DTM, and then click the right mouse button. The same context menu appears.
- Click **Connect**, to connect Unity Pro to the third-party module DTM. Now, the IP address and name of each module appears in bold lettering, indicating both devices are connected.




Now that Unity Pro is connected to both DTMs, you can proceed to calibrate the Scaime PME SWT 0100 weighing module.

- In the DTM Browser, select the third-party module DTM, click the right mouse button, and then navigate to and select: **Device menu -> Additional functions -> Calibration**:




- The Calibration screen opens, where you can perform calibration for the PME SWT 0100 weighing module:



- When calibration is complete, click **Apply**.

5.10. Resetting Device with Unity


PME SWT DTM provides a menu option to reset the device. The reset of device is helpful in the cases where change in configuration of the device requires restart of the module. The reset functionality is provided as a DTM menu as shown below.



To select the Reset functionality, user needs to right click the device DTM from DTM browse and select *Device Menu -> Additional Function -> Reset Device*

Please note that Reset Device menu is enabled only if the device is in online mode, otherwise it will be disabled.

On selecting the menu item Reset Device, user will be shown a confirmation dialog box with the text “Do you confirm resetting the device?”. If user presses “Yes”, then the Reset command will be sent to the device and the device will restart.



While the device restarts, the DTM will still be in connected mode. The DTM will wait for 1 minute for the device to be functional again. If the device does not become functional within 1 minute, the DTM will display “Communication Error” message.

While the device is restarting, if user again selects the Reset Device DTM menu, an information pop up will be displayed saying “Device reset is already in progress...” as shown below.


6. [Remote rack configuration of PME SWT module](#)

This chapter describes step by step procedure to configure PME SWT device on remote rack in M580 system. There are three major steps to configure the PME device on remote rack.

- Remote rack physical configuration with PME modules
- Device configuration on remote rack in Unity Pro
- Configuration transfer to device


6.1. Remote rack physical configuration with PME modules

The following diagram shows the complete setup of Remote rack along with connection with the M580 CPU.



Note: Firmware version for the remote backplane must be 1.0 or greater.


Configure drop number of the CRA using rotary switches as shown below:




For example if the drop number for the remote rack is 01, then the 10s digit should be 0 and 1s digit should be 1.

6.2. Device configuration on remote rack in Unity Pro:


Create new Unity project by selecting M580 CPU which supports RIO bus. The M580 CPUs which support RIO bus are: BME P58 2040, BME P58 3040 and BME P58 4040.




Go to Project Browser of the Unity Pro and double click EIO Bus (*Project Browser->Configuration->EIO bus*) tag as shown below:



In the EIO bus screen, select new device by right clicking on the selected part as shown below




Select appropriate rack for M580 remote drop from New Device popup menu. The rack, selected, should be from BME family and not from BMX family. Therefore user can select any of the first three BME racks available. Also provide topological address for the drop from 1-16. The topological address, set by user, should be the same as it is physically configured in the CRA device (refer to section 1.1).




Make sure that the Drop End communicator, selected, should be BME CRA 312 10.2 . If BMX CRA 312 xx.x is selected, then Unity will not allow adding PME SWT device to the remote rack.

Add proper power supply by right clicking on the first slot of remote rack and selecting proper power supply from Pop-up screen.





Now add PME SWT module by right clicking empty slot and selecting PME SWT module from new device Pop up screen.




Make sure that you do not select slot no: 2, 8, 10 and 11 to add PME SWT device as they do not have Ethernet port

Go to PLC bus (Project Browser->Configuration->PLC bus). Click on the Ethernet port available on the CPU which opens the port configuration. Change the TFTP setting to "Enabled".







To change CRA IP Address, Navigate to IPConfig tab and set the CRA IP address




After changing TFTP setting to "Enabled", click validate button




Open DTM browser screen from Menu *Tools* -> *DTM Browser* or with keyboard shortcut *Alt + Shift +1*. Right click the master DTM in the DTM browser and select *Add...* from context menu. From the *Add* popup screen, select *PME SWT 0100* device DTM and click *Add DTM* button



Provide the alias name for the DTM of your choice and click *OK* on *Device Property* popup screen.




Now open *M580 DTM* screen by double clicking *M580 DTM* in *DTM browser*. To configure the device name, go to the *address setting* tab of *PME SWT* device info page, select *Rack Identification* as *CRA*, provide the drop number which has been set for the *CRA* and finally provide slot number where the *PME SWT* device is put on the remote rack. If desired, user can change the *IP Address* of *PME SWT* device in *IP Address* field.



Click Apply of the M580 DTM page and click menu Build -> Rebuild All Project to build the Unity Pro project.

Now open the PME SWT DTM by double clicking the device in DTM browser. Open Identity tab of the DTM screen as show in figure below.




6.3. Device configuration transfer from Unity Pro:

Once step1 and step2 are over, Power cycle the M580 local bus as well as remote bus.


In UnityPro menu bar, go to *PLC->set address* and configure the address as follows, the media must be TCP/IP. You can verify the provided address is available or not using Test Connection.




In UnityPro menu bar, go to *PLC-> Connect* to connect with M580 CPU.



Once the connection is established with the M580 CPU, transfer the Unity Pro project from menu *PLC-> Transfer Project to PLC*



Once the PLC program is transferred, transfer the PRM file to FDR server from device DTM menu *Device Menu -> Additional Function -> Transfer to FDR server* option.




Once the Transfer to FDR Server function is successful, Power cycle the complete M580 system (both M580 local bus as well as CRA remote bus).

After power cycle, the M580 system along with Remote rack should be up and running.

7. Configuration with Unity Pro

The PME SWT is configured using DTM integrated into Schneider Electric Unity Pro software via the Ethernet backplane. From the Unity DTM browser, it is possible to open the Device Editor, which can be used to configure the weighing module parameters presented in the DTM.



7.1. Identity tab

This tab of UNITY DTM Browser allows showing the name and main specifications of the module.

The screenshot shows the 'Identity' tab of the UNITY DTM Browser. The interface includes a top toolbar, a header with the module name 'PMESWT0100', 'Weighing Module', and version '01.00', and the 'scaime' logo. Below the header, there are tabs for 'Identity', 'Ethernet Configuration', 'Application Configuration', and 'Process Data'. The 'Identity' tab is active, displaying 'Device Identity Parameters' and 'Device Name (For DHCP discovery)' sections. A red box highlights the 'Device Name (For DHCP discovery)' section, with a red arrow pointing to it and a red text label: 'Non modifiable DHCP parameters in Identity Tab of DTM screen'. The 'Device Identity Parameters' section lists: Module Name: PMESWT0100, Module Part Number: No, Partner Name: SCAIME, Product Family: Partner, Device Family: Weighing Module, and Version: 01.00. The 'Device Name (For DHCP discovery)' section lists: Rack Identification: Hx80, Slot Number: 1, and Device Name: Hx80_01_PMESWT01. Below these sections, there are two tables: 'Communication characteristics' and 'Measurement Input'. The 'Communication characteristics' table has two columns: 'Characteristic name' and 'Characteristic value'. The 'Measurement Input' table also has two columns: 'Characteristic name' and 'Characteristic value'. At the bottom, there are buttons for 'OK', 'Cancel', and 'Apply', and a status bar showing 'Disconnected' and 'Data Set'.

PMESWT0100
Weighing Module
01.00

scaime

Identity Ethernet Configuration Application Configuration Process Data

Device Identity Parameters

Module Name : PMESWT0100
Module Part Number : No
Partner Name : SCAIME
Product Family : Partner
Device Family : Weighing Module
Version : 01.00

Technology approved by
Schneider Electric

Device Name (For DHCP discovery)

Rack Identification : Hx80
Slot Number : 1
Device Name : Hx80_01_PMESWT01

Non modifiable DHCP parameters in Identity Tab of DTM screen

Communication characteristics

Characteristic name	Characteristic value
Communication	EtherNet/IP

Measurement Input

Characteristic name	Characteristic value
Input load cell Supply voltage	5 VDC
Measurement input	1 weighing channel, comprising up to 8 load cells
Internal Resolution	24 bit converter

OK Cancel Apply

Disconnected Data Set

BMEP58_E PME_SWT... PME_SWT... PME_SWT...

7.2. Application configuration and process data tab

This tab allows showing and change the module functional parameters for application configuration

Parameter	ID	Length in byte	Services supported	Type	Description
HMI address	1000	1	R/W	BYTE	Device external Modbus RTU communication interface address <ul style="list-style-type: none"> 1 to 127
HMI baud rate	1001	1	R/W	BYTE	Device external Modbus RTU communication interface baud rate <ul style="list-style-type: none"> 0 = 9600 bauds 1 = 19200 bauds 2 = 38400 bauds 3 = 57600 bauds 4 = 115200 bauds
HMI Panel Setting	1002	2	R/W	WORD	Auxiliary HMI panel control setting
• Language				Bits field (b ₀ -b ₃)	<ul style="list-style-type: none"> 0 = English 1 = French
• Reserved				Bits field (b ₄ -b ₇)	For evolution
• Keyboard visibility				BOOL(b ₈)	<ul style="list-style-type: none"> 0 = Visible 1 = Not visible
• Pass Word Management				BOOL(b ₉)	<ul style="list-style-type: none"> 0 = Disable 1 = Enable
• Panel locked Management				BOOL(b ₁₀)	<ul style="list-style-type: none"> 0 = Not locked 1 = Locked
• Reserved				Bits field (b ₁₁ -b ₁₂)	For evolution
HMI Password	1003	4	R/W	STRING	Protected by password device's functionalities or parameters against modification through HMI.
Input 0 Setting	1004	1	R/W	BYTE	Logical input I0 setting
• Assignment function				Bits field (b ₀ -b ₃)	<ul style="list-style-type: none"> 0 = None 1 = Tare 2 = Zero 3 = Cancel tare 4 = Zero in specified time 5 = Tare in specified time 6 = Active dosing process 15 = Test function
• Logic				BOOL(b ₄)	<ul style="list-style-type: none"> 0 = Negative 1 = Positive
• Reserved				Bits field (b ₅ -b ₇)	For evolution
Input 1 Setting	1005	1	R/W	BYTE	Logical input I1 setting
• Assignment function				Bits field (b ₀ -	<ul style="list-style-type: none"> 0 = None

Parameter	ID	Length in byte	Services supported	Type	Description
				b_3)	<ul style="list-style-type: none"> 1 = Tare 2 = Zero 3 = Cancel tare 4 = Zero in specified time 5 = Tare in specified time 6 = Active dosing process 15 = Test function
• Logic				BOOL(b_4)	0 = Negative 1 = Positive
• Reserved				Bits field (b_5 - b_7)	For evolution
Inputs Holding time	1006	2	R/W	UINT	Minimum time is ms to be elapsed before take into account input changed.
SOS1 outputs setting	1007	2	R/W	WORD	Logical dosing outputs S0(coarse feed) and S1(fine feed) setting
• SOS1 or Dosing process Activation				BOOL(b_0)	<ul style="list-style-type: none"> 0 = Disable 1 = Enable
• Logic				BOOL(b_1)	<ul style="list-style-type: none"> 0 = Negative 1 = Positive
• SOS1 dosing direction				BOOL(b_2)	<ul style="list-style-type: none"> 0 = Unloading 1 = Filling
• Dosing coarse feed mode				BOOL(b_3)	<ul style="list-style-type: none"> 0 = Only coarse feed output is enable at start 1 = Coarse & fine feed outputs are enable at start
• Dosing comparison source				BOOL(b_4)	<ul style="list-style-type: none"> 0 = Compare with Net weight 1 = Compare with Gross weight
• Reserved				Bits field (b_5 - b_{15})	For evolution
Coarse feed cut off point	1008	4	R/W	DWORD	Depending on the direction defined, S0 output goes to zero when that threshold is met <ul style="list-style-type: none"> 0 to 500.000
Fine feed cut off point	1009	4	R/W	DWORD	Depending on the direction defined, S1 output goes to zero when that threshold is met <ul style="list-style-type: none"> 0 to 500.000
Fine feed mask time	1010	2	R/W	UINT	It defines the time in ms after the CF, during which the module no longer checks the weight, to mask perturbations at feed change. <ul style="list-style-type: none"> 0 to 65535ms
Output S2 Setting	1011	1	R/W	BYTE	Logical output S2(Threshold control) setting
• S2 Activation				BOOL(b_0)	<ul style="list-style-type: none"> 0 = Disable output 2 threshold management

Parameter	ID	Length in byte	Services supported	Type	Description
					<ul style="list-style-type: none"> 1 = Enable output 2 threshold management
<ul style="list-style-type: none"> Logic 				BOOL(b ₁)	<ul style="list-style-type: none"> 0 = Negative 1 = Positive
<ul style="list-style-type: none"> Threshold mode 				BOOL(b ₂)	<ul style="list-style-type: none"> 0 = Windows 1 = Hysteresis
<ul style="list-style-type: none"> Threshold comparison source 				Bits field (b ₃ -b ₅)	<ul style="list-style-type: none"> 0 = Net weight 1 = Gross weight 2 = Flow measurement
<ul style="list-style-type: none"> Reserved 				Bits field (b ₆ -b ₇)	For evolution
S2 threshold low value	1012	4	R/W	DWORD	Depending on the threshold mode, S2 output changes state when that set point is met
S2 threshold high value	1013	4	R/W	DWORD	Depending on the threshold mode, S2 output changes state when that set point is met
Output S3 Setting	1014	1	R/W	BYTE	Logical output S3(Threshold control) setting
<ul style="list-style-type: none"> S3 Activation 				BOOL(b ₀)	<ul style="list-style-type: none"> 0 = Disable output 3 threshold management 1 = Enable output 3 threshold management
<ul style="list-style-type: none"> Logic 				BOOL(b ₁)	<ul style="list-style-type: none"> 0 = Negative 1 = Positive
<ul style="list-style-type: none"> Threshold mode 				BOOL(b ₂)	<ul style="list-style-type: none"> 0 = Windows 1 = Hysteresis
<ul style="list-style-type: none"> Threshold comparison source 				Bits field (b ₃ -b ₅)	<ul style="list-style-type: none"> 0 = Net weight 1 = Gross weight 2 = Flow measurement
<ul style="list-style-type: none"> Reserved 				Bits field (b ₆ -b ₇)	For evolution
S3 threshold low value	1015	4	R/W	DWORD	Depending on the threshold mode, S3 output changes state when that set point is met
S3 threshold high value	1016	4	R/W	DWORD	Depending on the threshold mode, S3 output changes state when that set point is met
A/D converter setting	1017	2	R/W	WORD	To define device internal sampling and rejection frequencies
<ul style="list-style-type: none"> Rejection frequency 				BOOL(b ₄)	<ul style="list-style-type: none"> 0 = 60 Hz 1 = 50 Hz
<ul style="list-style-type: none"> Sampling frequency 				Bits field (b ₀ -	If 50 Hz rejection If 60 Hz rejection

Parameter	ID	Length in byte	Services supported	Type	Description
				b_3)	<ul style="list-style-type: none"> 0 = 100 meas/s 1 = 50 meas/s 2 = 25 meas/s 3 = 12.5 meas/s 4 = 6.25 meas/s 11 = 400 meas/s 12 = 200 meas/s <ul style="list-style-type: none"> 0 = 120 meas/s 1 = 60 meas/s 2 = 30 meas/s 3 = 15 meas/s 4 = 7.5 meas/s 11 = 480 meas/s 12 = 240 meas/s
Low pass filter setting	1018	2	R/W	WORD	To define low pass filter activation and order
• Reserved				Bits field (b_0 - b_7)	• 0 = For evolution
• Filter order				Bits field (b_7 - b_{15})	<ul style="list-style-type: none"> 0 = low-pass filter disabled 2 = 2nd order low-pass filter 3 = 3rd order low-pass filter
Filter cut off frequency	1019	2	R/W	UINT	Low-pass filter cut-off frequency expressed in Hz and multiplied by 100 From 10 to 20000
Average filter depth	1020	2	R/W	UINT	<ul style="list-style-type: none"> 0 = Mean filter disabled 2, 4, 8, 16, 32, 64 and 128
Average flow rate depth	1021	2	R/W	UINT	• 2, 4, 8, 16, 32, 64 and 128
Flow rate unit	1022	2	R/W	STRING	
Metrology switches	1023	1	R/W	BYTE	Device legal mode management
• Legal for trade activation				BOOL(b_0)	<ul style="list-style-type: none"> 0 = Disable 1 = Enable
• Legal sealing activation				BOOL(b_1)	<ul style="list-style-type: none"> 0 = Disable 1 = Enable
• Reserved				Bits field (b_2 - b_7)	For evolution
Legal for trade version	1024	1	RO	BYTE	Legal mode firmware version
Legal for trade counter	1025	2	RO	UINT	The legal for trade counter is incremented every time if at least one (or several) of legal for trade settings has been modified
Legal for trade CRC16	1026	2	RO	UINT	New legal for trade checksum is calculated every time if at least one (or several) of legal for trade settings has been modified
Zero functions	1027	2	R/W	WORD	Device zero tracking and initial zero functions activation
• Zero tracking activation				BOOL(b_0)	<ul style="list-style-type: none"> 0 = Disable 1 = Enable

Parameter	ID	Length in byte	Services supported	Type	Description
<ul style="list-style-type: none"> Initial zero activation 				BOOL(b_1)	<ul style="list-style-type: none"> 0 = Disable 1 = Enable
<ul style="list-style-type: none"> Reserved 				Bits field (b_2 - b_{15})	For evolution
Stability criterion	1028	1	R/W	BYTE	Measurement stability criteria define <ul style="list-style-type: none"> 0 = (None) no motion detection (always stable) 1 = 0.25 division 2 = 0.5 division 3 = 1 division 4 = 2 divisions
Zero/Tare specified time	1029	2	R/W	UINT	Time in ms in which gross measurement average is done to make volatile dynamic zero or tare.
Preset tare value	1030	4	R/W	DWORD	This parameter contents user previous tare value and could be set on Net measurement on user command
Maximum capacity	1031	4	R/W	DWORD	Maximum weight that it is possible to weigh, without dead weight of the empty receiver
Calibration unit	1032	4	R/W	STRING	Weight measurement unit (mg, g, kg, t, lb...)
Scale interval	1033	2	R/W	UINT	The 'scale interval' is the minimal difference between two consecutive indicated values <ul style="list-style-type: none"> 1, 2, 5, 10, 20, and 50
Decimal point position	1034	1	R/W	BYTE	Number of digits after the decimal point <ul style="list-style-type: none"> 0, 1, 2, 3, 4, 5, and 6
Sensor sensitivity(mV/V)	1035	4	R/W	DWORD	Used to achieve theoretical calibration. Load cell sensitivity in mV/V at maximum capacity. This setting is expressed as a 10^{-5} value that means 7875 is equivalent to 0.07875 mV/V load cell sensitivity <ul style="list-style-type: none"> 0 up to 6 mV/V
Zero sensitivity(mV/V)	1036	4	R/W	DWORD	Used to achieve theoretical calibration. Load cell sensitivity in mV/V for the dead load. This setting is expressed as a 10^{-5} value that means 7875 is equivalent to 0.07875 mV/V <ul style="list-style-type: none"> -6 up to 6 mV/V
Number of segments	1037	2	R/W	UINT	Defines how many calibration loads reference will be used during the physical calibration <ul style="list-style-type: none"> 1, 2 and 3

<i>Parameter</i>	<i>ID</i>	<i>Length in byte</i>	<i>Services supported</i>	<i>Type</i>	<i>Description</i>
<i>Calibration load 1</i>	1038	4	R/W	DWORD	User weight value corresponding to 1 st calibration segment reference
<i>Calibration load 2</i>	1039	4	R/W	DWORD	User weight value corresponding to 2 nd calibration segment reference
<i>Calibration load 3</i>	1040	4	R/W	DWORD	User weight value corresponding to 3 rd calibration segment reference
<i>Calibration zero reference</i>	1041	4	R/W	DWORD	Zero reference measured during a physical calibration. Also used for theoretical zero calibration
<i>Global span adjustment</i>	1042	4	R/W	DWORD	Allows adjusting initial calibration. This setting is expressed as a 10^{-6} value that means 1000000 is equivalent to a span adjusting coefficient that is equal to 1.
<i>Span adjustment 1</i>	1043	4	R/W	REAL	Automatically produced during calibration process. Allows to restore a previous calibration
<i>Span adjustment 2</i>	1044	4	R/W	REAL	Automatically produced during calibration process. Allows to restore a previous calibration
<i>Span adjustment 3</i>	1045	4	R/W	REAL	Automatically produced during calibration process. Allows to restore a previous calibration
<i>Calibration place g value</i>	1046	4	R/W	DWORD	Allows compensating the gravity difference between device calibrated place and using place.
<i>Using place g value</i>	1047	4	R/W	DWORD	Allows compensating the gravity difference between device calibrated place and using place.
<i>Gross measurement</i>	1048	4	RO	DWORD	the 'gross weight' stands for the digital value after measurement scaling. It is affected by all the 'zero' functions
<i>Tare value</i>	1049	4	RO	DWORD	the 'tare weight' stores the volatile calibrated value which is subtracted from the 'gross weight' to give the 'net weight'
<i>Net measurement</i>	1050	4	RO	DWORD	the 'net weight' stands for the digital value after measurement scaling and tare subtraction
<i>Factory calibrated points</i>	1051	4	RO	DWORD	the 'factory calibrated points' contains the measurement value without the user calibration layer. That means it is directly linked to the analog input voltage and factory calibration
<i>flow rate</i>	1052	4	RO	REAL	Flow rate

Parameter	ID	Length in byte	Services supported	Type	Description
Measurement status	1054	2	RO	UINT	This parameter contains all information's related to the device internal measurement process status
• Reserved				Bits field (b ₀ -b ₁)	
• A/D converter fault				Bits field (b ₂ -b ₃)	<ul style="list-style-type: none"> 0 = Measurement is OK (no error) 1 = Gross weight < - (Max. capacity) 2 = Gross weight > (Max. capacity) 3 = Converter saturation or analog signal out of A/D input range
• Stability flag				BOOL(b ₄)	<ul style="list-style-type: none"> 0 = Measurement is not stable 1 = Measurement is stable
• Measurement out of ¼ division flag				BOOL(b ₅)	<ul style="list-style-type: none"> 0 = false 1 = True
• ROM Memory status				BOOL(b ₆)	<ul style="list-style-type: none"> 0 = Memory ok 1 = Memory failure (measurements shall be set to 0xFFFFFFFF)
• Preset tare process flag				BOOL(b ₇)	<ul style="list-style-type: none"> 0 = None 1 = At least one preset tare is processed
• Logical Input I0 state flag				BOOL(b ₈)	<ul style="list-style-type: none"> 0 = Disable 1 = Enable
• Logical Input I1 state flag				BOOL(b ₉)	<ul style="list-style-type: none"> 0 = Disable 1 = Enable
• Logical Output S0(Dosing coarse feed) state flag				BOOL(b ₁₀)	<ul style="list-style-type: none"> 0 = Disable 1 = Enable
• Logical Output S1(Dosing fine feed) state flag				BOOL(b ₁₁)	<ul style="list-style-type: none"> 0 = Disable 1 = Enable
• Logical Output S2(Threshold) state flag				BOOL(b ₁₂)	<ul style="list-style-type: none"> 0 = Disable 1 = Enable
• Logical Output S3(Threshold) state flag				BOOL(b ₁₃)	<ul style="list-style-type: none"> 0 = Disable 1 = Enable
• Tare process flag				BOOL(b ₁₄)	<ul style="list-style-type: none"> 0 = None 1 = At least one tare is processed
• Zero/Tare process flag				BOOL(b ₁₅)	<ul style="list-style-type: none"> 0 = None 1 = At least one zero/tare is processed
Device status	1055	2	RO	UINT	Informations on device calibration and option
• Reserved				BOOL(b ₀)	
• User calibration status				BOOL(b ₁)	<ul style="list-style-type: none"> 0 = Any user calibration is applied 1 = At least one user calibration is processed

<i>Parameter</i>	<i>ID</i>	<i>Length in byte</i>	<i>Services supported</i>	<i>Type</i>	<i>Description</i>
<ul style="list-style-type: none"> User calibration type 				Bits field (b ₂ -b ₄)	<ul style="list-style-type: none"> 0 = None 1 = Physical calibration is set 2 = Theoretical calibration is set
<ul style="list-style-type: none"> Reserved 				Bits field (b ₅ -b ₇)	For evolution
<ul style="list-style-type: none"> Load cell wiring mode 				BOOL(b ₈)	<ul style="list-style-type: none"> 0 = 4-wire 1 = 6-wire
<ul style="list-style-type: none"> Terminal RS485 resistor 				BOOL(b ₉)	<ul style="list-style-type: none"> 0 = Terminal resistor is not set 1 = Terminal resistor is set
<ul style="list-style-type: none"> Reserved 				Bits field (b ₁₀ -b ₁₅)	For evolution
Command register	1056	2	R/W	UINT	Allows user to send functional command to the device.
Response register	1057	2	RO	UINT	Allows user to send functional command to the device.
Load cell wiring mode and terminal resistor	1058	1	R/W	BYTE	
<ul style="list-style-type: none"> Load cell wiring 				BOOL(b ₀)	<ul style="list-style-type: none"> 0 = 4-wire 1 = 6-wire
<ul style="list-style-type: none"> terminal resistor 				BOOL(b ₁)	<ul style="list-style-type: none"> 0 = Terminal resistor is not set 1 = Terminal resistor is set

8. Module specifications

The general characteristics for the PME SWT weighing modules are as follows.

General			
Backplane Power consumption	At 24 VDC	max	150 mA
Power dissipation		max	3,6 W
Bridge excitation voltage			5 VDC
Input sensor range min/max			+/-7.8 mV/V
Minimum input sensor resistance			42 Ohm
Sensor connection			4/6 wires, software selection
Reliability			> 500 000 Hours at Tambient = 30 °C
Dimensions			100x100x32 mm3
Weight			170 g
Standard Operating temperature			-10 °C + 60°C
Metrological temperature			- 10 °C + 40°C
Storage temperature			- 40 ° + 85 °C
EMC compliance			IEC 61131-2:2007
Positive logic input			
Number of type 3 inputs			2
Nominal input values		Voltage	24 VDC
		Current	7 mA
Threshold input values	At 1	Voltage	≥ 11 V
		Current	≥ 2 mA (for U ≥ 11 V)
	At 0	Voltage	≤ 5 V
		Current	≤ 1.5 mA
Input impedance	At nominal U		3.4 kΩ
Reverse polarity			Protected
IEC 61131-2 compliance			Type 3
Input Dielectric Strength			1500 V rms, 50/60 Hz for 1 min
Dielectric Strength	Output/ground or output/internal logic		1500 V rms, 50/60 Hz for 1 min
	Between groups of inputs and outputs		500 V rms, 50/60 Hz for 1 min
Type of Input			Current sink
Positive logic static outputs			
Number of outputs			4
Nominal values	Voltage		± 24 V _{DC}
	Current		0.25 A

<i>Threshold values</i>	<i>Voltage (including ripple)</i>	$\pm 30 V_{DC}$
	<i>Current/channel</i>	0.3 A
	<i>Current/module</i>	4 x 0.3 A
<i>Compatibility with IEC 61131-2 direct inputs</i>		<i>Yes (Type 3)</i>
<i>Built in protection</i>	<i>Against overvoltage</i>	<i>Yes, by TVS diode</i>
	<i>Against short circuit and overload</i>	<i>No protection</i>
<i>Dielectric Strength</i>	<i>Output/ground or output/internal logic</i>	<i>1500 V rms, 50/60 Hz for 1 min</i>
	<i>Between groups of inputs and outputs</i>	<i>500 V rms, 50/60 Hz for 1 min</i>
<i>Resistance of insulation</i>		<i>> 10 MOhm</i>

<i>Metrological specifications</i>		
<i>Input signal resolution</i>		<i>1 000 000</i>
<i>Conversion rate</i>		<i>6.25 to 400 conv./s</i>
<i>Accuracy class</i>		<i>+0.005 %FS</i>
<i>Linearity deviation</i>		<i>+0.003 % FS</i>
<i>Thermal zero shift</i>		<i>+0.00015 % / °C</i>
<i>Thermal span shift</i>		<i>+0.0002 % / °C</i>
<i>Internal resolution</i>		<i>24 bits</i>
<i>Scaled measured resolution</i>		<i>+0.500 000 pts</i>
<i>Internal Conversion rate</i>		<i>6.25 .. 400 conv/s</i>
<i>Max update frequency of data on the backplane</i>		<i>100 Hz</i>


9. Installing PME SWT weighing module

9.1.1. Maximum Configuration in PME SWT weighing module

The weighing module PME SWT is standard format and therefore occupies a single position in the BME XBP xx00 racks. It can be installed in all positions on the rack except for the first two (PS and 00) which are reserved for the rack power supply module (BMX CPS xxxx) and processor module (BME P58 xxxx) respectively, and the slots 2, 8, 10 and 11 (12 slots racks only) which are reserved for gateway products.

They are powered by the rack back bus, and can be positioned either in the standard rack or in an extendable rack.

Warning: With a 12 slots rack, slots 2, 8, 10 and 11 are reserved for gateway products and are not available for module installation.



- Max. number of modules on each X80 RIO drop – 7 PME SWT
- Max. number of modules on each M580 local CPU rack – 6 PME SWT

9.1.2. Installation precaution

The installation and removal of the weighing module can be done with the CPU **switched on** (without risk of damage to the module or disruption to the CPU).


9.1.3. Order of Module Installation

Install modules in the selected rack in Unity Pro in this order:

1. Install the adapter module
2. Install a power supply
3. Install PME SWT weighing modules

9.1.4. Mounting a Module

Use this procedure to install adapters and I/O modules in a rack:

Step	Action
1	<p>Hold the module at an angle and mount it on the 2 hooks near the bottom of the backplane. The figure shows the correct way to hold the module:</p> 
2	Swing the module up so that the connector engages the backplane connector.
3	Use a phillips-head screw driver to tighten the screw at the top of the module 2...4 in-lbs (0.22 to 0.45 N•m) of torque.

9.1.5. [Replacing a Module](#)

You can replace an Modicon X80 module at any time using another module with compatible firmware. The replacement module obtains its operating parameters over the backplane connection from the CPU. The transfer occurs immediately at the next cycle to the device.

9.1.6. [Installation Results](#)

Applying power to the main local rack after the adapter module is installed can result in either:

Successful installation:

- Initialization is finished.
- Interconnections to other modules are validated (drop adapter module only).


Unsuccessful installation:

- Initialization does not finish.
- Interconnections to other modules are not validated (drop adapter modules only).

You can see the status of the installation on the adapter LED display.

9.1.7. [External Features](#)

This weighing module has the same dimensions and installation constraints as the other modules in the Modicon X80 product line:



1 LED display

2 Connector


3 Connector

9.1.8. PME SWT Keying Pin

The PME SWT weighing module is designed to be installed on an Ethernet backplane in the main remote rack. The adapter supports the Modicon X80 I/O and partner modules with Ethernet. The bus connector is shown in items 1 below.

The adapter also has a keying pin (item 2 below) to keep it from being installed on a BMX BKP.xxxx backplane.

Rear view of the adapter module:




- 1. Ethernet backplane connector
- 2. Keying pin

10. Interfaces


The primary task of PME SWT is the measurement of the current weight value thru one input load cell channel. This channel is pre-adjusted in the factory. This makes possible the theoretical adjustment of the scale without adjustment weights as well as module replacement without a new adjustment of the scale.

PMESWT possesses one RS485 port for the connection of local tactile HMI for weight display and weighing function operations.

PMESWT also integrates two digital inputs for weighing function triggering and four programmable digital outputs dedicated to weight level monitoring and dosing control.



10.1.1. Connection



The following table describes the front connection of the PME SWT 0100.

Connector	PIN number	Labelling	Description	
3	11	RB/TB	RS485 data cable TB	RS485
	10	RA/TA	RS485 data cable TA	
	9	GND	RS485 data cable GND	
	8	I0+	Digital input 0	Input
	7	I _{COM}	Digital Input common	
	6	I1+	Digital input 1	
	5	S _{COM}	Digital Output Common	Output
2	4	S0	Digital output 0	
	3	S1	Digital output 1	
	2	S2	Digital output 2	Load cell
	1	S3	Digital output 3	
	7	Shld	Shield	
	6	Sig-	Measurement cable load cell -	
	5	Sig+	Measurement cable load cell +	
	4	Sen-	Sensor cable load cell -	
	3	Exc-	Supply load cell -	
	2	Sen+	Sensor cable load cell +	
	1	Exc+	Supply load cell +	

10.2. Load cells input



4 or 6-wire strain gauges sensors with sensitivity from 0.1 mV/V to 6 mV/V

10.2.1. 4 and 6-wire load cells

In a 4-wire load cell, the cable is part of the temperature compensating system of the load cell. The load cell is calibrated and compensated with a certain amount of cable attached.

In a 6-wire load cell, the cable is not part of the temperature compensating system of the load cell. 2 sense lines are connected to the controller which adjusts its output voltage to compensate for any resistance change in the cable. The advantage of using this system is the possibility to cut the 6-wire load cell cable to any length.

Parameter	Possible Value	Default	Description
Load Cell Mode	4/6 wires	4 wires	Must be compliant with the type of connector connected to the PME SWT: 4 or 6 wires.



10.2.2. Multiple load cells connection

In multiple load cell weighing systems, load cells can be wired in parallel by joining the load cell cable core ends of the same color. For this, SCAIME provides ALCJB junction boxes. The output signal is then the average of the individual output signals.




CAUTION

In case of multiple load cells connection, PME SWT can supply excitation voltage to a maximum of 8 load cells (350 Ω output resistance)

Sometimes it is necessary to trim the output of each individual load cell to avoid corner load differences, which are caused by difference in load cells output resistance or unequal load distribution.

Trimming can be done by adjusting variable resistors (P1...Pn) placed into the excitation paths of the ALCJB.



10.2.3. Cable extension

Extension cables must be shielded and of low capacitance. We recommend the use of SCAIME cables, which satisfy these requirements. To compensate the effects of resistance changes in the extension cable, a 6-wire extension cable must be used



CAUTION

- *The wiring distance between load cells and the module should not exceed 300m*
- *Load cell cables should be kept away from power circuits, with a minimum of 1m.*
- *Power supply cables should be crossed at right angles.*

10.3. Auxiliary RS485 communication port

The PME SWT module offers a serial link to carry over the weight to an external dedicated display panel:

- Non-isolated half-duplex RS485, 2-wire connection
- Fixed format : 1 start bit, 8 data bits and 2 stop bits
- Maximum connection distance 30m
- A jumper allows activating an internal termination resistor.
- The transmission lines are polarized with a 1,5 k Ω resistor.
- Communication protocol is Modbus-RTU and PME SWT is a slave device

The parameters linked to this auxiliary port are the following:

<i>Parameter</i>	<i>Possible Value</i>	<i>Default</i>	<i>Description</i>
RS485 resistor option	ON / OFF	OFF	Line termination resistor for RS485 HMI line
Address HMI	1 to 128	1	PME SWT slave N° on the Modbus network
Baud rate HMI	9,6 to 115,2Kbds	9,6Kbds	Communication rate of auxiliary RS485 port
HMI Language	FR / ENG	ENG	Language of HMI menu
HMI keyboard visibility	Yes / No	No	Enable/disable the HMI functions keys
HMI Password activation	Yes / No	No	Enable/disable password for HMI setup access
Password	4 visible characters	"5555"	Password value for HMI setup access

All Modbus-RTU Master can be connected to the weighing module to:

- Read PME SWT process data: Gross/Net weight, Flow rate, Measurement status, Input/output status
- Send weighing function commands to the PME SWT module: Zero, Tare, or Calibration...

10.3.1. eNodTouch display panel


SCAIME can provide **eNodTouch**, a compact graphic operator interface with the following specifications:

Display type	Back lighted 3.4" STN Monochrome LCD
Resolution	W200 x H80 pixels
Touch Panel type	Resistive film
Input voltage	24VDC, 3.0W
Dimension	W116.5 x H77.5 x D28mm

10.4. Discrete Input/output

The PME SWT is equipped of 2 discrete inputs and 4 discrete outputs used to trigger actions. They are connected using a screw terminal block.



Input / output connections:



10.4.1. Discrete inputs

PME SWT has 2 opto-isolated digital inputs with the following specifications:

Examples of detector and push-button wiring




Each input can be individually set to positive or negative logic and can be assigned to trigger a weighing function.

10.4.2. Discrete outputs

The PME SWT has 4 opto-insulated digital outputs (Static relays) with the following specifications:

Weighing module discrete outputs are used to trigger actions on threshold crossings. Each output can be individually set to positive or negative logic.


Examples of output wiring



Weighing module discrete outputs are used to trigger actions on threshold crossings. Each output can be individually set to positive or negative logic.

10.5. LED Indicators

The PME SWT weighing module is fitted with LEDs which display the status of the module. The following diagram shows the weighing module display screen:



- 1 LED display
- 2 Connector
- 3 Connector

The various possible faults are grouped in the following table:

LED	Continually lit	Flickering, Flashing, or Blinking	OFF
RUN (Green)	<i>Normal operation</i>	<i>Flickering: Firmware upgrade in progress</i>	<i>Module faulty, switched OFF or starting up</i>
ERR (Red)	<i>Critical error, or not valid MAC address, or no Ethernet link</i>	<i>Flashing: Communication to PAC lost Blinking: No IP address (2x); Invalid configuration (3x); Duplicate IP address (4x); awaiting served IP address (5x); Invalid IP address (6x); Error on the daughter board (7x)</i>	<i>Module starting up, or no runtime error</i>
STATUS (Green)	<i>User calibrated</i>	<i>Calibration in progress</i>	<i>Factory calibrated</i>
STATUS (Red)	<i>- Converter saturation - No communication with Converter - EEPROM memory corruption</i>	<i>Measurement Out of range</i>	<i>No error</i>
STAB (Yellow)	<i>Instability</i>	-	<i>Stable Measurement stable or instability not defined</i>
S0 (Green)	<i>S0 digital output ON</i>	-	<i>S0 digital output OFF</i>
S1 (Green)	<i>S1 digital output ON</i>	-	<i>S1 digital output OFF</i>
S2 (Green)	<i>S2 digital output ON</i>	-	<i>S2 digital output OFF</i>

11. [Identification parameters](#)

<i>Read Only Parameter</i>	<i>Possible Value</i>	<i>Description</i>
Application software version	1.xx.yy	Version number of the applicative software part
Legal software version	0 to 255	Version number of the Legal for trade software part
Boot loader version	0.xx.yy	Version number of the Boot loader software

12. Scaling parameters

Parameter	Possible Value	Default	Description
maximum capacity	1 to 1 000 000	500 000	Maximum weight that it is possible to weigh, without dead weight of the empty receiver.
scale interval	1, 2, 5, 10, 20, 50	1	The 'scale interval' is the minimal difference between two consecutive indicated values.
Decimal point position	0 to 7	0	Number of digits after the decimal point.
unit	4 visible char.	" kg "	Weight measurement unit (mg, g, kg, t, lb...)

12.1.1. Maximum capacity

The 'maximum capacity' stands for the maximum sensor/load cell signal range. When the absolute value of the gross measurement exceeds its value plus 9 divisions, the b_3 bit (positive overloading) or the b_2 bit (negative overloading) of the measurement status is set to 1 (it can activate a logical output if it is assigned to the 'defective measurement' function).

The zero acquisition (on request or at power-up) is done only if the gross measurement value is contained between a $\pm 10\%$ range of the 'maximum capacity' ($\pm 2\%$ if the *legal for trade* option is active).

The 'maximum capacity' setting also allows calibrating **PME SWT** in case of a theoretical calibration in association with the sensor sensitivity. Measurement scaling will be automatically adapted so as to deliver a gross measurement value equivalent to the 'maximum capacity' for an analog signal corresponding to the sensor sensitivity.

After a theoretical calibration, the maximum capacity can be changed to fit to the application.

12.1.1. Decimal point position

Although **PME SWT** measurements are integer values it is however possible to store a 'decimal point position' so as to design a display related to the application. Its value represents the number of decimal digits. If the variable is set to Zero, it means that decimal point is not used.

Note: the decimal point is directly integrated to SCMBus protocol frames (see § SCMBus).

13. Metrological parameters

Parameter	Possible Value	Default	Description
Load Cell Mode	4/6 wires	4 wires	Must be compliant with the type of connector connected to the PME SWT: 4 or 6 wires.
Zero Tracking	Yes / No	No	Enable the Zero tracking function
Initial Zero	Yes / No	No	Enable the Zeroing at power-on.
stability criterion	Disable, 0.25, 0.5, 1, 2d	0.25d	Defines a stability interval, related to scale interval. A measurement is stable if X (depending on A/D conversion rate) consecutive measurements are included in the stability interval.
Zero/Tare specified time	0 to 65535 ms	100 ms	Use in dynamic application where stability could not reached. It's the maximum time in which stability is searched for taking "Zero/Tare in specified time". If after that time, there is no stability, a special Zero/Tare calculation is operated.
Preset Tare value	0 to Max. capacity	0	Used to manually introduce a Tare value. A previous calculated tare can be restored using this variable.

13.1.1. Zero Tracking and Initial Zero

The zero tracking and the initial zero setting can be respectively enabled by setting b_0 bit or b_1 bit to 1. When activated, both options are effective on a $\pm 10\%$ range of the 'maximum capacity' ($\pm 2\%$ if the 'legal for trade mode' is enabled).

13.1.2. Stability criterion

The stability criterion defines the interval on which measurements are considered as stable. Motion is indicated by the measurement status. A measurement is stable if consecutive measurements following the reference measurement are included in the stability interval (see following table) else the current measurement becomes the new reference measurement.

A/D conversion rate (meas/s)		Number of values used to consider stable measurement
50-Hz rejection	60-Hz rejection	
6,25	7,5	1
12,5	15	2
25	30	3
50	60	5
100	120	9
200	240	17
400	480	33
800	960	65
1600	1920	129

14. Flow control parameters

The PME SWT module calculates the flow rate using the following parameters


Parameter	Possible Value	Default	Description
Flow filter depth	2, 4, 8, 16, 32, 64, 128	$N = 8$	The filtered flow is the sliding average of N instantaneous flow calculated at each measurement acquisition (Net weight).
Flow Time unit	h, mn, s	s	Used for flow rate scaling in weight unit/time unit

Current Flow rate : $F = (f_1 + f_2 \dots + f_n) / N$

with

- f_i : Instantaneous flow rate : $f_i = \Delta W_i / T$
- ΔW_i : Net weight variation during time T
- T : Flow calculation time : This calculation time depend on the parameters N and Δt
- Δt : Weight sampling time, depend on A/D converter rate.
- N : Flow filter depth

By using this calculation: The first flow value is available from the time T of flow calculation. After time T , the flow rate is recalculated at each measurement.



15. Process Data parameters

The table below shows the implicit exchange objects which apply to the PME SWT.

15.1.1. Measurement variables

Object	Description
Gross Measurement	the 'gross measurement' stands for the digital value after measurement scaling. It is affected by all the 'zero' functions
Tare Value	the 'tare measurement' stores the calibrated value which is subtracted from the 'gross measurement' to give the 'netmeasurement'.
Net Measurement	the 'net measurement' stands for the digital value after measurement scaling and tare subtraction.
Factory calibrated points	the 'factory calibrated points' contains the measurement value without the user calibration layer. That means it is directly linked to the analog input voltage
Flow rate	Flow rate

15.1.1. Measurement status

Status indicator	Possible Values	Description
A/D error	0, 1,2,3	A/D Error = 0 -> No A/D converter error A/D Error = 1 -> Gross measurement < - Max. capacity. A/D Error = 2 -> Gross measurement > Max. capacity. A/D Error = 3 -> No communication with the converter or Converter out of range
Stability	TRUE/FALSE	Indicate that measurement is stable according to the stability criterium
Measurement out of ¼ division	TRUE/FALSE	Indicate measurement is Zero in the ¼ of division (OIML indicator)
EEPROM failure / corrupt	TRUE/FALSE	Error with internal memory of the PME SWT
Tare / Zero running	TRUE/FALSE	Tare or Zero has been processing
Tare has been processed	TRUE/FALSE	A tare has been processed on the PME SWT and is applied to the measurement
Calibration has been processed	0 to 7	A calibration has been processed on the PME SWT and is applied to the measurement:
Running calibration type		
Preset Tare status	TRUE/FALSE	A preset tare device was engaged

15.1.2. I/O status

Status indicator (I/O)	Description
I0, I1	the 'I/O level' object allows reading any time PME SWT discrete inputs and outputs level.
S0, S1, S2, S3	S0 and S1 level cause corresponding S0 and S1 led update

16. Functional commands

PME SWT is able to handle several functional commands thanks to a couple of registers:


- the command register : dedicated to accept the functional commands
- the response register : gives the state of the command currently being processed by PME SWT

The following tables show the functional commands available for the weighing module:

16.1. Sending Functional Commands through Unity

The weighing module is able to handle several functional commands codes from user application. To achieve a command, user has to write specific code into device **“Command Register”**. Device replies to user functional command through **“Response Register”**.

Command and response registers are available on unity in IO scanning connection (see in capture below an example of Unity animation table).



Name	Value	Type	Comment
REDUNDANCY_OWNER	0	BOOL	
GLOBAL_STATUS	0	BOOL	
SERVICE_STATUS	24	BYTE	
SNTP_SERVICE	0	BOOL	
SNMP_SERVICE	1	BOOL	
FDR_SERVICE_B1	1	BOOL	
FDR_SERVICE_B2	0	BOOL	
FDR_SERVICE_B3	0	BOOL	
FDR_SERVICE_B4	0	BOOL	
ETH_PORT1_INFO	1	BYTE	
ETH_PORT1_FUNCTION_B1	1	BOOL	
ETH_PORT1_FUNCTION_B2	0	BOOL	
Free2	0	BYTE	Unused Variable
GrossMeasurement	2502	DINT	
NetMeasurement	2	DINT	
FactMeasurement	127379	DINT	
TareValue	2500	DINT	
CurrentFlowRate	0.0	REAL	
InstFlowRate	0.0	REAL	
LegalForTradeCount	8	UINT	
LegalForTradeCRC	36685	UINT	
RespRegister	2	UINT	
Reserved_0	0	UINT	
PresetTareValue_OP	0	UDINT	
Reserved_1	0	DINT	
Measurement_Status	16400	UINT	
DeviceStatus	518	UINT	
Reserved_2	0	UINT	
Free3		ARRAY[0..1] OF ...	Unused Variable
Outputs		T_PME_SWT_...	Output Variables
ASS_OUT_TAG	0.0	REAL	
BLOCK_LENGTH	0	UINT	
BLOCK_IDENTIFIER	0	UINT	
BLOCK_STATUS	0	UINT	
SIGNATURE	0	UINT	
PLC_FW_VERSION	0	UINT	
PLC_STATE	0	BYTE	
PLC_START	0	BYTE	
PLC_TYPE_ID	0	BYTE	
PLC_AB_ADDRESS_ID	0	BYTE	
DATA_FRESHNESS_ID	0	BYTE	
Free4		ARRAY[0..3] OF ...	Unused Variable
CdeRegister	212	UINT	
PresetTareValue_IP	0	DINT	

User functional commands supported by the weighing module are:

<i>Command Name</i>	<i>Code</i>	<i>Description</i>	<i>Note</i>
Clearing functional registers	00_H	Causes Command and Response registers to be set to 0.	It is recommended to send this command before sending any functional commands
Device reset	D0_H		
Saving on Flash Memory	D1_H		
Restore to factory setting	D2_H	Device will lose its current configuration (calibration etc.)	
Zero	D3_H	Set to 0 Gross and Net Measurements (if stability reached in 5s)	
Tare	D4_H	Set to 0 Net Measurement (if stability reached in 5s)	
Cancel tare	D5_H	Set to 0 Tare value	
Cancel current command	D6_H	Ended current command	
Theoretical scaling	D7_H	Device theoretical calibration with known sensitivity value at max capacity	
Zero adjustment	D8_H	Set current load as device zero reference	
Start physical calibration process	D9_H	Put device in to physical calibration mode	
Calibration zero acquisition	DA_H	Set current load as device zero reference(if stability in 10s)	Possible if device is previously putted into calibration mode
Segment 1 acquisition	DB_H	(if stability reached in 10s)	Possible if Zero step success
Segment 2 acquisition	DC_H	(if stability reached in 10s)	Possible if Segment 1 step success
Segment 3 acquisition	DD_H	(if stability reached in 10s)	Possible if Segment 2 step success
Saving Calibration on Flash Memory	DE_H		Possible if all calibrations step success
Theoretical zero	E3_H	Device theoretical calibration with known sensitivity value at dead load	
Span adjustment	E4_H		
Pre-set tare	E5_H	Manually set current tare weight with user preference value defined in PresetTareValue_IP parameter	
Zero in specified time	E6_H	Set to 0 Gross and Net Measurements(even if not stability)	
Tare in specified time	E7_H	Set to 0 Net Measurement (even if not stability)	

16.2. Device Response Register Status

The “**RespResponse**” parameter gives the status of the functional command currently being processed by the weighing module. It is automatically updated by the device if value of “**CdeRegister**” parameter has changed such as new command received. Followings are the response register status which could be reported to user by the weighing module:

Response Register Status	Description
00_H	Device is free/ready to accept a new command from user
01_H	Current command execution is in progress
02_H	Current command execution is complete (Successfully)
03_H	Current command execution is complete (Failure)

- # Step 1:

Preparing device to receive a new command

The screenshot displays the SCAIME software interface. On the left, the 'Project Browser' shows the 'Structural view' with 'PME_SWT_0100' selected. The main window shows the 'Modification' table for the device. The table lists various parameters and their current values. Two red arrows point to specific parameters: one to 'RespRegister' (value 0) and another to 'CdeRegister' (value 0). Red text annotations are present: 'Response is set to 0 (ready for next command)' near the 'RespRegister' row and 'Clearing command and response registers' near the 'CdeRegister' row.

Name	Value	Type	Comment
REDUNDANCY_OWNER	0	BOOL	
GLOBAL_STATUS	0	BOOL	
SERVICE_STATUS	24	BYTE	
SNTP_SERVICE	0	BOOL	
SNMP_SERVICE	1	BOOL	
FDR_SERVICE_B1	1	BOOL	
FDR_SERVICE_B2	0	BOOL	
FDR_SERVICE_B3	0	BOOL	
FDR_SERVICE_B4	0	BOOL	
ETH_PORT1_INFO	1	BYTE	
ETH_PORT1_FUNCTION_B1	1	BOOL	
ETH_PORT1_FUNCTION_B2	0	BOOL	
Free2	0	BYTE	Unused Variable
GrossMeasurement	2500	DINT	
NetMeasurement	0	DINT	
FactMeasurement	127301	DINT	
TareValue	2500	DINT	
CurrentFlowRate	0.0	REAL	
InstFlowRate	0.0	REAL	
LegalForTradeCount	8	UINT	
LegalForTradeCRC	36685	UINT	
RespRegister	0	UINT	
Reserved_0	0	UINT	
PresetTareValue_OP	0	UDINT	
Reserved_1	0	DINT	
Measurement_Status	16400	UINT	
DeviceStatus	518	UINT	
Reserved_2	0	UINT	
Free3		ARRAY[0..1] OF...	Unused Variable
Outputs		T_PME_SWT...	Output Variables
ASS_OUT_TAG	0.0	REAL	
BLOCK_LENGTH	0	UINT	
BLOCK_IDENTIFIER	0	UINT	
BLOCK_STATUS	0	UINT	
SIGNATURE	0	UINT	
PLC_FW_VERSION	0	UINT	
PLC_STATE	0	BYTE	
PLC_START	0	BYTE	
PLC_TYPE_ID	0	BYTE	
PLC_AB_ADDRESS_ID	0	BYTE	
DATA_FRESHNESS_ID	0	BYTE	
Free4		ARRAY[0..6] OF...	Unused Variable
CdeRegister	0	UINT	
PresetTareValue_IP	0	DINT	

- # Step 2:

Sending the functional command code to the module, **Example:** Tare = D4_H = 212_d

Host PC < 192.168.2.1 > BMEP58_ECPU
Remote Bus
Distributed Bus
< Ethernet IP:192.168.2.55 > PME_SWT_0100

Project Browser
Structural view
Derived Data Types
Derived FB Types
Variables & FB Instances
Elementary Variables
Derived Variables
Device DDT Variables
IO Derived Variables
Elementary FB Instances
Derived FB Instances
Motion
Communication
Program
Tasks
Events
Timer Events
I/O Events
Animation Tables
Table
Operator Screens
Documentation

Name	Value	Type	Comment
REDUNDANCY_OWNER	0	BOOL	
GLOBAL_STATUS	0	BOOL	
SERVICE_STATUS	24	BYTE	
SNTP_SERVICE	0	BOOL	
SNMP_SERVICE	1	BOOL	
FDR_SERVICE_B1	1	BOOL	
FDR_SERVICE_B2	0	BOOL	
FDR_SERVICE_B3	0	BOOL	
FDR_SERVICE_B4	0	BOOL	
ETH_PORT1_INFO	1	BYTE	
ETH_PORT1_FUNCTION_B1	1	BOOL	
ETH_PORT1_FUNCTION_B2	0	BOOL	
Free2	0	BYTE	Unused Variable
GrossMeasurement	2581	DINT	
NetMeasurement	-1	DINT	
FactMeasurement	133439	DINT	
TareValue	0	DINT	
CurrentFlowRate	375.0	REAL	
InstFlowRate	1300.0	REAL	
LegalForTradeCount	8	UINT	
LegalForTradeCRC	36685	UINT	
RespRegister	1	UINT	
Reserved_0	0	UINT	
PresetTareValue_OP	0	UDINT	
Reserved_1	0	DINT	
Measurement_Status	0	UINT	
DeviceStatus	518	UINT	
Reserved_2	0	UINT	
Free3	0	ARRAY[0..1] OF ...	Unused Variable
Outputs			Output Variables
ASS_OUT_TAG	0.0	REAL	
BLOCK_LENGTH	0	UINT	
BLOCK_IDENTIFIER	0	UINT	
BLOCK_STATUS	0	UINT	
SIGNATURE	0	UINT	
PLC_FW_VERSION	0	UINT	
PLC_STATE	0	BYTE	
PLC_START	0	BYTE	
PLC_TYPE_ID	0	BYTE	
PLC_AB_ADDRESS_ID	0	BYTE	
DATA_FRESHNESS_ID	0	BYTE	
Free4	0	ARRAY[0..6] OF ...	Unused Variable
CdeRegister	212	UINT	
PresetTareValue_IP	0	DINT	

Tare process is in progress (searching for weight stability for example)

Tare command

- # Step 3:

In case of failure during functional command execution

Host PC < 192.168.2.1 > BMEP58_ECPU
Remote Bus
Distributed Bus
< Ethernet IP:192.168.2.55 > PME_SWT_0100

Project Browser
Structural view
Derived Data Types
Derived FB Types
Variables & FB Instances
Elementary Variables
Derived Variables
Device DDT Variables
IO Derived Variables
Elementary FB Instances
Derived FB Instances
Motion
Communication
Program
Tasks
Events
Timer Events
I/O Events
Animation Tables
Table
Operator Screens
Documentation

Name	Value	Type	Comment
REDUNDANCY_OWNER	0	BOOL	
GLOBAL_STATUS	0	BOOL	
SERVICE_STATUS	24	BYTE	
SNTP_SERVICE	0	BOOL	
SNMP_SERVICE	1	BOOL	
FDR_SERVICE_B1	1	BOOL	
FDR_SERVICE_B2	0	BOOL	
FDR_SERVICE_B3	0	BOOL	
FDR_SERVICE_B4	0	BOOL	
ETH_PORT1_INFO	1	BYTE	
ETH_PORT1_FUNCTION_B1	1	BOOL	
ETH_PORT1_FUNCTION_B2	0	BOOL	
Free2	0	BYTE	Unused Variable
GrossMeasurement	2500	DINT	
NetMeasurement	2500	DINT	
FactMeasurement	127293	DINT	
TareValue	0	DINT	
CurrentFlowRate	0.0	REAL	
InstFlowRate	0.0	REAL	
LegalForTradeCount	8	UINT	
LegalForTradeCRC	36685	UINT	
RespRegister	3	UINT	
Reserved_0	0	UINT	
PresetTareValue_OP	0	UDINT	
Reserved_1	0	DINT	
Measurement_Status	16	UINT	
DeviceStatus	518	UINT	
Reserved_2	0	UINT	
Free3	0	ARRAY[0..1] OF ...	Unused Variable
Outputs			Output Variables
ASS_OUT_TAG	0.0	REAL	
BLOCK_LENGTH	0	UINT	
BLOCK_IDENTIFIER	0	UINT	
BLOCK_STATUS	0	UINT	
SIGNATURE	0	UINT	
PLC_FW_VERSION	0	UINT	
PLC_STATE	0	BYTE	
PLC_START	0	BYTE	
PLC_TYPE_ID	0	BYTE	
PLC_AB_ADDRESS_ID	0	BYTE	
DATA_FRESHNESS_ID	0	BYTE	
Free4	0	ARRAY[0..6] OF ...	Unused Variable
CdeRegister	212	UINT	
PresetTareValue_IP	0	DINT	

Net measurement is not set to 0 because tare has not been processed

Failure during tare process execution (device is not allow to make tare in these conditions...)

Tare command

- # Step 4:

Functional command execution is complete successfully

Host PC
192.168.2.1 > BMEP58_ECPU
Remote Bus
Distributed Bus
Ethernet IP:192.168.2.55 > PME_SWT_0100

Structural view
Derived Data Types
Derived FB Types
Variables & FB instances
Elementary Variables
Derived Variables
Device DDT Variables
IO Derived Variables
Elementary FB Instances
Derived FB Instances
Motion
Communication
Program
Tasks
MAST
Events
Timer Events
I/O Events
Animation Tables
Table
Operator Screens
Documentation

Modification
Force

Name	Value	Type	Comment
REDUNDANCY_OWNER	0	BOOL	
GLOBAL_STATUS	0	BOOL	
SERVICE_STATUS	24	BYTE	
SNTP_SERVICE	0	BOOL	
SNMP_SERVICE	1	BOOL	
FDR_SERVICE_B1	1	BOOL	
FDR_SERVICE_B2	0	BOOL	
FDR_SERVICE_B3	0	BOOL	
FDR_SERVICE_B4	0	BOOL	
ETH_PORT1_INFO	1	BOOL	
ETH_PORT1_FUNCTION_B1	1	BOOL	
ETH_PORT1_FUNCTION_B2	0	BOOL	
Free2	0	BYTE	Unused Variable
GrossMeasurement	2500	DINT	
NetMeasurement	0	DINT	
FactMeasurement	127291	DINT	
TareValue	2500	DINT	
CurrentFlowRate	0.0	REAL	
InstFlowRate	0.0	REAL	
LegalForTradeCount	8	UINT	
LegalForTradeCRC	36685	UINT	
RespRegister	2	UINT	
Reserved_0	0	UINT	
PresetTareValue_OP	0	UDINT	
Reserved_1	0	DINT	
Measurement_Status	16400	UINT	
DeviceStatus	518	UINT	
Reserved_2	0	UINT	
Free3		ARRAY[0..1] OF...	Unused Variable
Outputs		T_PME_SWT_...	Output Variables
ASS_OUT_TAG	0.0	REAL	
BLOCK_LENGTH	0	UINT	
BLOCK_IDENTIFIER	0	UINT	
BLOCK_STATUS	0	UINT	
SIGNATURE	0	UINT	
PLC_FW_VERSION	0	UINT	
PLC_STATE	0	BYTE	
PLC_START	0	BYTE	
PLC_TYPE_ID	0	BYTE	
PLC_AB_ADDRESS_ID	0	BYTE	
DATA_FRESHNESS_ID	0	BYTE	
Free4		ARRAY[0..6] OF...	Unused Variable
CdeRegister	212	UINT	
PresetTareValue_IP	0	DINT	

Table
PME_SWT_...

Net measurement is set to 0
Tare process successfully done
Tare command

16.3. Example with Pre-set Tare Parameter

On following screen shot example, both device real time output parameters are using to perform preset tare action.

- # Step 1:

Write user preference pre-set tare value to the device

- # Step 2:

Send user pre-set tare command code to the device

- # Step 3:

Observe device response and pre-set tare effect on Net Measurement value

The screenshot displays the LTI M browser interface. The top-left pane shows the Host PC connection to the device < 192.168.2.1 > BMEP58_ECPU. The bottom-left pane shows the Project Browser with a tree view of the project structure, including Derived Data Types, Variables & FB instances, Motion, Communication, Program, Tasks, MAST, Events, Timer Events, I/O Events, Animation Tables, Table, Operator Screens, and Documentation.

The main pane shows a table of device parameters. The table has columns for Name, Value, Type, and Comment. The parameters are listed as follows:

Name	Value	Type	Comment
REDUNDANCY_OWNER	0	BOOL	
GLOBAL_STATUS	0	BOOL	
SERVICE_STATUS	24	BYTE	
SNTP_SERVICE	0	BOOL	
SNMP_SERVICE	1	BOOL	
FDR_SERVICE_B1	1	BOOL	
FDR_SERVICE_B2	0	BOOL	
FDR_SERVICE_B3	0	BOOL	
FDR_SERVICE_B4	0	BOOL	
ETH_PORT1_INFO	1	BYTE	
ETH_PORT1_FUNCTION_B1	1	BOOL	
ETH_PORT1_FUNCTION_B2	0	BOOL	
Free2	0	BYTE	Unused Variable
GrossMeasurement	2501	DINT	
NetMeasurement	2001	DINT	
FactMeasurement	127326	DINT	
TareValue	500	DINT	
CurrentFlowRate	0.0	REAL	
InstFlowRate	0.0	REAL	
LegalForTradeCount	8	UINT	
LegalForTradeCRC	36685	UINT	
RespRegister	2	UINT	
Heservd_U	0	UINT	
PresetTareValue_OP	500	UINT	
Reserved_1	0	DINT	
Measurement_Status	16560	UINT	
DeviceStatus	518	UINT	
Reserved_2	0	UINT	
Free3		ARRAY[0..1] OF ...	Unused Variable
Outputs		T_PME_SWT_...	Output Variables
ASS_OUT_TAG	0.0	REAL	
BLOCK_LENGTH	0	UINT	
BLOCK_IDENTIFIER	0	UINT	
BLOCK_STATUS	0	UINT	
SIGNATURE	0	UINT	
PLC_FW_VERSION	0	UINT	
PLC_STATE	0	BYTE	
PLC_START	0	BYTE	
PLC_TYPE_ID	0	BYTE	
PLC_AB_ADDRESS_ID	0	BYTE	
DATA_FRESHNESS_ID	0	BYTE	
Free4		ARRAY[0..6] OF ...	Unused Variable
CdeRegister	229	UINT	
PresetTareValue_IP	500	DINT	

Red annotations highlight the pre-set tare process:

- effect on Net measurement
- Pre-set tare process is successfully done
- Pre-set tare value currently setting in the device
- Pre-set tare command
- User pre-set tare value defined (sending to device)

16.4. [System commands](#)

Command	Parameters	Description
Reset	-	Software Reboot
EEPROM backup	-	PME SWT configuration and calibration are stored in a non-volatile memory (EEPROM). If changes are made in the device configuration, sending to PME SWT the 'EEPROM backup' functional command will allow to keep these modifications after a power shutdown
Restore default settings	-	Causes PME SWT to be set back to its default factory settings, including calibration parameters.
Cancel command	-	Cancel process command (calibration, tare...)

16.4.1. [Reset](#)

This reboot phase is necessary if the external HMI address or/and the baud rate are modified and some settings changes are only taken into account after an EEPROM storage followed by a reset.

16.4.2. [EEPROM backup](#)

PME SWT configuration and calibration are stored in a non-volatile memory (EEPROM). If changes are made in the device configuration, sending to **PME SWT** the 'EEPROM storage' functional command will allow **PME SWT** to keep these modifications after a power shutdown or the reception a 'reset' functional command.

Moreover the settings listed below need to be stored and will only be taken into account at the next device reboot:

- Global span adjusting coefficient
- calibration place g value
- place of use g value
- stability criterion
- legal for trade mode
- Initial zero
- A/D conversion rate

16.4.3. [Restore default settings](#)

The 'restore default settings' command causes **PME SWT** to be set back to its default configuration. The default configuration corresponds to the one on delivery that means with factory settings. Be careful when using this command, all the default settings are recovered including the stored calibration and the legal for trade indicators.

16.5. [Weighing control commands](#)

Command	Parameters	Description
Zero	-	<i>PME SWT acquires a volatile zero (gross measurement is set to 0) if the following conditions are respected :</i> <i>measurement is stable</i> <i>Gross measurement is within a $\pm 10\%$ ($\pm 2\%$ if "legal" is enabled) range of the 'maximum capacity'.</i> <i>Otherwise, after 5s, the command is cancelled and error is reported.</i>
Tare	-	<i>PME SWT acquires a volatile tare (net measurement is set to 0) value if the measurement is stable otherwise, after 5s, the command is cancelled and an error is reported</i>
Zero in specified time	Zero/Tare specified time	<i>Use in dynamic application where stability could not reached.</i>
Tare in specified time		<i>The stability condition is replace by a maximum time in which stability is searched for taking Zero or Tare. If after that time, there is no stability, a special Zero/Tare calculation is operated.</i>
Preset Tare	Preset Tare value	<i>With this command it is possible to retrieve a defined tare value. Net measurement is set to Gross minus Preset tare.</i>
Cancel Tare	-	<i>Erases the current tare value</i>

16.5.1. [Zero](#)

When receiving a 'zero' functional command, **PME SWT** acquires a volatile zero (gross measurement is set to 0) value if the following conditions are respected:

- measurement is stable
- Current gross measurement is within a $\pm 10\%$ ($\pm 2\%$ if the legal for trade option is enabled) range of the 'maximum capacity'.

Otherwise, after 5 seconds the command is cancelled and an execution error is reported.

16.5.2. [Tare](#)

When receiving a 'tare' functional command, **PME SWT** acquires a volatile tare (net measurement is set to 0) value if the measurement is stable otherwise, after 5 seconds the command is cancelled and an execution error is reported (see 'measurement status').

16.5.3. [Cancel tare](#)

This command erases the current tare value if at least one tare has been previously processed.

16.5.4. [Cancel last command](#)

This command sets the response register to **00_H** and allows **PME SWT** to ignore the functional command previously received (for example to exit a sequential procedure like a physical calibration).

16.5.5. [Logical outputs 1-4 activation/deactivation](#)

If the corresponding logical outputs are assigned to the 'level on request' function, they can be enabled/disabled by transmitting one of these functional commands. Upon first reception, the corresponding output is enabled and on next reception it will be disabled. If the requesting logical output is assigned to the wrong function, **PME SWT** reports an error.

17. Filters

17.1.1. Introduction

The PME SWT module is equipped with a high performance **24 bit A/D converter** with high speed carrier frequency of **3840 Hz** for an Input load cell signal range of **±7.8 mV/V**.

There are 2 available filtering levels which can be associated:

- Bessel low-pass filter
- Mean value filter

Except for the A/D conversion rate that is always enabled, none of these filters is mandatory. However, to perform accurate measurements we recommend setting a combination of filters.

17.1.2. Bessel low-pass filter parameters

Parameter	Possible Value	Default
Low pass Order	Disable, 2, 3, 4	3
Low pass Cut-Off frequency	0.10 Hz to 200 Hz	5 Hz


For the suppression of periodic vibrations, a Bessel low-pass digital filter can be applied as an output of the A/D converter.

The minimum value for cut-off frequency depend on the A/D converter rate:

0.10 Hz for 6.25 meas/s converter rate

4 Hz for 400 meas/s converter rate

The specification of the cut-off frequency has a decisive significance for the suppression of periodic interferences. The response time of the weighing system to the change of the measured value is determined by the cut-off frequency.



Step response of 4th order Bessel, with $F_c=2$ Hz

17.1.1. Mean-value filter

The Mean-value filter is used to calm the weight value when there are random interferences.

Parameter	Possible Value	Default	Description
Mean Filter depth	Disable, 2, 4, 8, 16, 32, 64, 128	Disable	A sliding average, where the result is the average of the last n measurements (n =depth) can be applied as an output of the Bessel filter.

17.1.2. A/D converter parameters

The signal resolution is related to the conversion rate. The conversion rate might be chosen as low as possible, particularly for static applications. For dynamic applications, a compromise must be found between the measurement rate and the low-pass filter cut-off frequency. Choose a measurement rate that rejects the mains frequency harmonics according to the place of use, 50 or 60Hz.

Parameter	Possible Value		Default	Description	
A/D Frequency rejection	50 Hz, 60 Hz		50 Hz	The A/D converter have In-built adjustable low-pass filter with frequency rejection of 50 Hz or 60 Hz harmonics.	
A/D conversion rate	50 Hz	60 Hz	100 Hz	Resol.	Filtered measurement frequency is adjustable from 6.25 to 480 Hz The following table shows the Noise-free resolution, related to the conversion rate.
	6.25 Hz	7.5 Hz		19 bits	
	12.5 Hz	15 Hz		19 bits	
	25 Hz	30 Hz		18 bits	
	50 Hz	60 Hz		18 bits	
	100 Hz	120 Hz		17 bits	
	200 Hz	240 Hz		16 bits	
	400 Hz	480 Hz		16 bits	



To reach an accurate and stable measurement:

- In static applications, the conversion rate might be chosen as low as possible.
- In dynamic applications, the use of post-filters allows the suppression of periodic or random interferences to increase the speed/precision performance of weighing

Note: To be applied, any modification of this setting must be followed by an EEPROM back up and device reboots (hardware or software).

Note: Recursive filters like **PME SWT** low-pass filters are computed according to the filter order, the desired cut-off frequency and the sampling rate. There are some limitations to respect in order to ensure a safe functioning of the signal processing. They are listed in the table below:

A/D conversion rate (meas/s)	min low-pass cut-off frequency (Hz)		A/D conversion rate (meas/s)	min low-pass cut-off frequency (Hz)	
50 Hz rejection			60 Hz rejection		
	2nd order	3rd order		2nd order	3rd order
6.25	0.10	0.10	7.5	0.10	0.10
12.5	0.10	0.10	15	0.10	0.15
25	0.10	0.15	30	0.15	0.20
50	0.15	0.25	60	0.20	0.30
100	0.25	0.50	120	0.30	0.60
200	0.50	1.00	240	0.60	1.20
400	1.00	2.00	480	1.20	2.40
800	2.00	4.00	960	2.40	4.80
1600	4.00	8.00	1920	4.80	9.60

18. Discrete Input parameters

Each discrete input can be individually set according to the following parameters.

Parameter	Possible Value	Default	Description
I0 functioning I1 functioning	None	I0: Zero I1: Tare	the input has no function
	Zero		See related command
	Tare		
	Zero in specified time		
	Tare in specified time		
	Cancel Tare		Special mode for module testing
	Test		
	Start Dosing process		
I0 logic I1 logic	Positive, Negative	Positive	defines the edge (or level) that triggers input function
Inputs Holding time	0 to 65535 ms	100 ms	Minimum required stabilization time of the logical inputs before their activation

19. Discrete Output parameters

Weighing module discrete outputs are used to trigger actions on threshold crossings. Each output can be individually set to positive or negative logic

The functions assigned to these outputs are separated in two groups:

- S0 and S1 outputs are used to control threshold crossing for 2-feed dosing control
- S2 and S3 output are freely configurable on measurement threshold monitoring



19.1.1. S0 and S1 output parameters

- The Coarse Feed (CF) cut-off point is associated with output S0,
- The Fine Feed (FF) cut-off point is associated with output S1.



The threshold check manages the outputs according to the following parameters:

Parameter	Possible Value	Default	Description
S0 & S1 Activation	Enabled, disabled	disabled	Enable or disable the output management.
S0 & S1 logic	Positive, negative	Positive	defines the edge (or level) that triggers outputs function
S0 & S1 Direction	Filling, Unloading	Filling	Corresponds to the direction in which the thresholds are recognized
S0 & S1 Coarse Feed mode	S0, S0+S1	S0	Concerns the coarse feed phase: Only S0 output, or S0 and S1 at the same time.
S0 & S1 Comparison Source	Net, Gross	Net	Define which value is checked with cut-off values
Coarse Feed Cut-off point	0 to Max Capacity	0	Depending on the direction defined, S0 and S1 outputs go to zero when these thresholds are met.
Fine Feed Cut-off point	0 to Max capacity	0	
Fine Feed mask time	0 to 65535 ms	0	It defines the time after the CF, during which the module no longer checks the weight, to mask perturbations at feed change.

- illustration describing the output operating according to Filling direction with CF mode = S0+S1



- illustration describing the output operating according to Unloading direction with CF mode = S0





19.1.2. S2 and S3 output parameters

The threshold check manages the output S_x ($x = 2$ or $x = 3$) according to the following parameters:

Parameter	Possible Value	Default	Description
S_x Activation	Enabled, disabled	disabled	Enable or disable the output management
S_x Logic	Positive, Negative	Positive	defines the edge (or level) that triggers input function
S_x threshold mode	Windows, Hysteresis	Windows	See diagram
S_x Output Comparison source	Net, Gross, Flow	Net	Define which value is checked with set point values
S_x Set point High value	0 to Max Capacity	0	Depending on the threshold mode, S2 and S3 outputs change state when these set points are met.
S_x Set point Low value	0 to Max capacity	0	

Illustration describing the output operating according to threshold mode:



20. Legal for trade

The legal for trade options are a set of functions and indicators that are generally used in weighing applications. They have an impact on the device behavior regarding the metrological requirements and track every configuration change that may affect the measurement determination.

NOTE

The PME SWT does not yet benefit from OIML approval for a use in legal for trade applications. Despite this, PME SWT was designed to comply with the OIML R76 recommendations.

20.1.1. Legal for trade parameters

Parameter	Possible Value	Default	Description
Legal for trade mode	Yes / No	No	Enable or disable criteria and parameters related to the use in OIML compliance.
Legal for trade Sealing	Yes / No	No	Enable or disable the software sealing of metrological parameters concerned by OIML compliance

20.1.2. Legal for trade Information (Read only)

Parameter	Possible Value	Default	Description
Legal counter	0 to 65535	0	Automatically updated by the module (see above)
Legal checksum	0 to 65535	0	

20.1.3. "Legal for trade" considerations

If 'legal for trade sealing' is activated, all the involved parameters will be available in read only, until the legal for trade sealing is deactivated.

At 'Legal for trade sealing' activation and deactivation, the 'legal for trade counter' is incremented, a new 'legal for trade checksum' is calculated and EEPROM storage is realized.

'Legal for trade sealing' activation is possible only if 'Legal for trade mode' is activated

The 'legal for trade mode' parameter activation leads to the following changes:

- The ratio "maximum capacity" divided by "scale interval" must be <6 000
- Tare function is impossible if gross measurement is negative.
- The range allowing making a Zero is reduced from $\pm 10\%$ to $\pm 2\%$ of maximum capacity
- The measurement value variations cannot be read during the 15 seconds that follow the device reset and during zero and tare acquisitions

Parameters involved by 'Legal for trade sealing'

- Legal for trade mode
- Stability criterion
- Zero Tracking and Initial Zero
- Scaling parameters (maximum capacity, scale interval, decimal point position, unit)
- Calibration parameters (Number of segments, Calibration loads 1/2/3, Global span adjusting coefficient, calibration place g value, place of use g value, sensor sensitivity...)
- Filtering parameters (A/D Conversion rate, Frequency rejection, Low pass order and cut off frequency...)




21.1. Introduction

The PME SWT is factory calibrated as following: **500 000 points for a 2 mV/V load cell input signal.**

Initial calibration can be modified for a better adjustment to the usage. All these adjustments refer to the factory calibration, allowing module replacement without a new adjustment of the scale.

To achieve these various types of adjustments the following options and procedures are available (See §7.3 for calibration commands):

- Physical calibration involving known loads to physically put on the weighing system.
- Theoretical calibration involving calculating the sensitivity of the load cell for the user-defined corresponding capacity.



CAUTION

In industrial context, because of the environment, choosing a resolution of more than 5 000 points assumes that there are rigorous installation precautions.

21.2. Calibration parameters

Parameter	Possible Value	Default	Description
Number of segments	1 to 3	1	Defines how many calibration loads are used during the physical calibration.
Calibration load 1/2/3	1 to 1 000 000	0 / 0 / 0	User weight values corresponding to each calibration segment.
Sensor sensitivity	0 to 6.0000 mV/V	2.00000	Used to achieve theoretical calibration. Load cell sensitivity in mV/V at maximum capacity.
Zero sensitivity	-6 to 6.0000 mV/V	0	Used to achieve theoretical calibration. Load cell sensitivity in mV/V for the dead load.
Calibration Zero	0 to $\pm 1\,000\,000$	0	Zero reference measured during a physical calibration. Also used for theoretical cal.
Global span adjusting coefficient	0.9 to 1.1000000	1.0000000	Allows to adjust initial calibration
calibration place g value	> 0	9.805470	Allows compensating the gravity difference between calibration place and using place.
Place of use g value	> 0	9.805470	Allows compensating the gravity difference between calibration place and using place.
Span coefficient 1/2/3	> 0		Automatically produced during calibration. Allows to restore a previous calibration

21.2.1. Calibration loads 1/2/3

Before starting a physical calibration procedure, each calibration segment must be given a corresponding user value (for example, 1000 points for a 1 kg load).

21.2.2. Sensor sensitivity

The 'sensor sensitivity' setting is used to achieve a theoretical calibration. The stored value for this parameter is the **load cell sensitivity in mV/V** for the low-level analog channel

The user can adapt the value delivered by **PME SWT** for the associated signal using the 'maximum capacity' and the 'sensor sensitivity'.

This setting is expressed with a 10^{-5} factor (197500 is equivalent to a 1.975 mV/V load cell sensitivity or a 1.975 V input voltage).

21.2.1. Zero sensitivity

The 'Zero sensitivity' value contains the offset in factory calibrated points that can be added/subtracted (if its value is positive or negative) to the zero calibration value when using the 'zero sensitivity' functional command. Once the command has been successfully achieved, this register is set to 0.

Note: The 'Zero sensitivity' value is not stored into EEPROM memory and is always equal to 0 after a device power-up or a software reset

21.2.2. Calibration Zero

Calibration Zero value corresponds to the A/D converter points measured during the 'zero acquisition' step of a physical calibration.

For a theoretical calibration this value must be set. It can be set automatically with the 'zero' command.

Note: To be applied, any modification of this setting must be followed by an EEPROM back up and device reboots (hardware or software).

21.2.1. Global span adjusting coefficient

The '*span adjusting coefficient*' allows adjusting initial calibration. Adjustment applies linearly on the whole calibration curve. This coefficient has a 10^{-6} factor (1000000 is equivalent to a span adjusting coefficient that is equal to 1).

Note: To be applied, any modification of this setting must be followed by an EEPROM back up and device reboots (hardware or software).

21.2.1. Calibration place g value / place of use g value

When the calibration place and the place of use of a measuring chain are different, a deviation can appear due to the difference of g (gravity) between the 2 places.

The PME SWT calculates a ratio applied to the measure which compensates the difference of gravity between the 2 places.

The g value are expressed in 10^{-6} m.s^{-2} (9805470 is equivalent to $g = 9.805470 \text{ m.s}^{-2}$).

Note: To be applied, any modification of this setting must be followed by an EEPROM back up and device reboots (hardware or software).

21.2.2. Span coefficients 1/2/3

These coefficients are computed and written during calibration process. Writing these coefficients could be done if you want to restore a previous calibration.

Note: To be applied, any modification of this setting must be followed by an EEPROM back up and device reboots (hardware or software).


21.3. Physical calibration

21.3.1. Physical calibration commands


Command	Parameters	Description
Start Physical calibration	-	First step of the sequential calibration procedure. Set PME SWT in calibration mode.
Physical calibration Zero	-	Second step of the physical calibration procedure. This step consists to acquire stable measurement with no load on the scale. If stability is not reach after 5 seconds, the command is cancelled and error is reported.
Phy. Cal. load 1	number of calibration loads, Calibration load 1 2 / 3	Next steps consist to acquire stable measurements with known loads (value in corresponding parameter) placed on the scale by sending the 'Phy. cal. load X' command where X depends on 'number of calibration segments' parameter If stability is not reach after 5 s, the command is cancelled.
Phy. Cal. load 2		
Phy. Cal. load 3		
Store calibration	Zero cal. Calibration span 1 / 2 / 3	Only if all the previous steps were successful, next step consists in storing the calculated calibration parameters in EEPROM.

Physical Calibration procedure

number of calibration load = 1




Physical Calibration procedure with number of calibration load = 3



21.3.2. Physical calibration example


- Open calibration windows (PME SWT -> Device menu -> Additional functions -> calibration)




- Choose the maximum capacity (ex 5000 for a 5 kg scale -> gram precision)
- Choose the “Unit” (“g” in this example), the “decimal point position” (0 in this example), and the “scale interval” (1 to display every gram in this example). These parameters are for display.
- Select “physical calibration”:




PME SWT 0100
Weighing Module
01.00



- Choose the “number of segments” according to the number of loads you have for calibration (up to 3, this example is 2).
- Change the “calibration load 1, 2 and 3” values according to the loads you have (unit is the “maximum capacity” unit: in this example maximum capacity is 5000 for 5 kg, so with 2 loads of 1 kg, write “1000” in “Calibration load 1”, and “2000” (2 x 1 kg) in “calibration load 2”).
- Click “Apply”, “Start” and follow the instructions written on the window:
- Remove load, then click next
- Wait for the “OK” message, and put your first load down on the scale, then click next



- Wait for the “OK” message, and add your second load on the scale, then click next



- Click “Ok” to end the physical calibration
- Physical calibration is successfully done. This calibration will be erased after a reset. If you want to keep it after a reset, click on “Save memory” (save into the EEPROM of the PME SWT).

PME SWT 0100 Calibration Process

User informations guide

Please check there is no load on the load cell then click Next button to launch zero acquisition

.....Please wait / zero acquisition in progress..... OK

Please deposit a load equivalent to : 1000 then click Next button to start the first segment acquisition.

.....Please wait / segment 1 acquisition in progress.....OK

Please deposit a load equivalent to : 2000 then click Next button to start the 2nd segment acquisition.

.....Please wait / segment 2 acquisition in

Calibration results

Zero result

Segment 1 result

Segment 2 result

Segment 3 result

End of calibration process with success

Home

Save Memory

Next

21.1. [Partial Physical calibration](#)

21.1.1. [Zero adjustment commands](#)

Zero adjustment	Parameters	Description
Zero adjustment	-	<p>Allows acquiring stable measurement with no load on the scale to set the calibration Zero.</p> <p>If correctly achieved, this calibration zero must then be saved by the 'store calibration' command.</p> <p>This command can be used any time and has no effect on the span.</p>

21.1.2. [Zero adjustment example](#)

- Select "Zero adjustment"
- Check that you do not have any load on the scale.
- Click "start" to start calibration and store in EEPROM.
- Zero adjustment is done. Click "ok" to end.
- This calibration will be erased after a reset. If you want to keep it after a reset, click on "Save memory" (save into the EEPROM of the PME SWT).

21.1.3. [Span adjustment commands](#)

Span adjustment	Parameters	Description
Span adjustment	Calibration load 1	<p>Allows acquiring stable measurement with known load on the scale to set the calibration span. If correctly achieved, the number of calibration load is set to 1 and calibration span 1 is calculated.</p> <p>this calibration span must be saved by the 'store calibration' command.</p> <p>This command can be used any time and has no effect on the current calibrated zero.</p>

21.1.4. [Span adjustment example](#)

Span adjustment is usually done after a Zero adjustment. Sometimes you cannot do both at the same time (Silo filling for example). This is why these commands can be done separately.


- Select "span adjustment"
- Change the calibration load, according to the load you have for calibration
- Click "Apply" to send to the device, and "start" to start calibration.
- Span adjustment is done. Click "ok" to end.
- This calibration will be erased after a reset. If you want to keep it after a reset, click on "Save memory" (save into the EEPROM of the PME SWT).

21.2. Theoretical calibration

21.2.1. Theoretical calibration commands

Command	Parameters	Description
Theoretical scaling	Sensor sensitivity, maximum capacity	<p>This command involves the 'maximum capacity' and the 'sensor sensitivity' settings. An automatic scaling to migrate from the factory calibration to the user calibration.</p> <p>This calibration must be saved by the 'store calibration' command.</p>
Theoretical Zero	Zero sensitivity	<p>From the 'Zero sensitivity' parameter, this command calculate the zero in factory calibration pts.</p> <p>This calibration must be saved by the 'store calibration' command.</p> <p>This command can be used at any time and has no effect on the span.</p>

These commands are used for example to calibrate a silo impossible to empty or fill with a known load:



21.2.2. Theoretical calibration example

PME SWT 0100 Calibration Process

Scaling Parameters

Maximum capacity: 5000 Scale interval: 1

Unit: g Decimal point position: 0

Calibration Modes

Theoretical Calibration


Calibration Parameters

☒ Sensor sensitivity: 1.85555

☐ Zero sensitivity: 0.00000

Start Apply

- Select « theoretical calibration » and change the « sensor sensitivity » (unit is mV/V at maximum capacity) or the « Zero sensitivity » (unit is mV/V without any load). Click « Apply » to send parameters to the PME SWT. You can usually find these parameters value on the calibration reports of the load cells (or sensor).
- Click “start” to start calibration with the parameters and store in EEPROM.



- Theoretical calibration is done. Click “ok” to end.
- This calibration is automatically saved in EEPROM (keep after reset).